

# PHILIPS

## Saeco

Super-automatic  
espresso machine

Xelsis

Integrated milk jug & frother

Mirror Stainless Steel



HD8946/47



## Multi-beverage, multi-user with full automated dual cleaning milk carafe

With the Xelsis each and every family member can enjoy his or her favorite coffee specialty. Thanks to the unique multi-user function up to 6 personal user profiles can be created and for each profile up to 9 beverages can be personalized.

### Authentic Italian coffee perfection

- Perfect milk froth thanks to the integrated milk carafe
- Milk specialties without the wait thanks to a double boiler
- Coffee without burnt taste thanks to 100% ceramic grinders

### Set the beverages to suit your taste

- Personalize your coffee in 6 user profiles
- Play with the coffee's richness with our adjustable grinders
- Boost coffee crema and body

### Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Hygienic milk frothing thanks to automated dual cleaning

# Highlights

## 100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

## 8 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 8 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

## 6 user profiles



This Saeco espresso machine comes with 6 customizable profiles that memorize your personal preference for different coffee drinks. This makes it very easy to get a perfect tailor-made cup of coffee although you are not the only one using the machine.

## Automatic dual cleaning carafe



This Saeco espresso machine comes with a fully automated dual clean function for its milk carafe. The dual cleaning uses two independent steam cycles to swiftly rinse your milk carafe after each coffee drink you prepare, for a fresh milk drink everytime. Hygienic milk frothing was never this easy.

## Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

## Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee or milk frothing temperatures, this Saeco fully automatic

espresso machine guarantees professional performance and speed everytime. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous without waiting.

## Integrated milk carafe



Enjoy your milk specialties with the automated milk carafe with auto-clean. Simply pour milk into the carafe, plug it into the machine and select your preferred coffee drink. Whether it is a latte macchiato, cappuccino or caffelatte, your drink will be served within seconds. The carafe of your Saeco espresso machine conveniently comes with auto-clean, which means two automatic steam-rinsing cycles will clean your carafe's tubes after every use for a fresh milk taste everytime.

## Crema and body boost



This Saeco features our patented crema and body boost. This dial, conveniently located at your machine's spout, allows you to smoothly adjust the counter pressure changing your espresso's body and crema. Try it yourself and find your favorite taste.

# Specifications

## Perfect Espresso

**Espresso technology:** Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor, Cup warmer

## Service

1-year guarantee

## Technical specifications

**Supported coffee types:** Ground coffee, Whole coffee beans

**Water pressure in pump:** 15 bar (perfect espresso)

**Removable brewing group**

**Country of origin:** Designed in Italy, Made in Italy

**Cord length:** 80 cm

**Number of water boilers:** 2 boilers (instant

steam)

**Frequency:** 60 Hz

**Power:** 1500 W

**Voltage:** 120 V

**Boiler material:** Stainless steel (Inox)

## Multi-Beverage

**Milk Variations:** Frothing degree adaptor, Integrated auto milk function, Milk quantity selector, Removable milk carafe

## Easy to use

**Cleaning and maintenance:** Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle

**Usage:** Adjustable coffee dispenser, Bypass for grinded coffee, Cup holding surface, Frontal

access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank

## Weight and dimensions

**Product weight:** 16.1 kg

**Maximum cup height:** 150 mm

**Product dimensions (L x D x H):** 280 x 370 x 420 mm

**Coffee bean capacity:** 350 gr

**Waste container capacity:** 14 servings

**Milk carafe capacity:** 0.5 L

**Water tank capacity:** 1.6 L

## Design

**Colour:** Stainless steel

**Materials and finishing:** Full stainless steel

