

# PHILIPS

Food processor

Pure Essentials  
Collection

1000 W

Compact 2 in 1 setup

3.4 L bowl



HR7774/30



## Effortless excellence

Powerful food processor with bigger tube and bowl

This state-of-the-art food Philips processor has some of the most advanced technologies. Its versatility is ensured by 7 accessories which easily perform 30+ functions.

### Powerful precision

- 1000 W motor
- Ice and pulse functions for chopping and crushing
- Adjustable blade for slices between 1-7 mm

### Effortlessly easy

- 7 accessories to easily perform 30+ functions
- XL feeding tube takes whole fruits or vegetables
- Up to 7 portions in 1 go with the XL bowl
- One touch (dis)assembly

### Stylishly compact

- Compact 2-in-1 setup saves countertop space

### Reliably durable

- Dishwasher safe accessories

# Highlights

## 30+ functions



The – dishwasher safe – accessories are a kneading tool for mixing batter and for heavy kneading. A stainless steel chopping knife to prepare meat and vegetables. Two metal disks to handle medium and fine shredding and grating. Break resistant blender of 1.5l for blending, crushing up to stirring different ingredients. A citrus press for pressing citrus fruits. And a balloon beater for whipping and whisking and handling light batter.

## Adjustable slicing blade

With the adjustable slicing blade, you can make slices as thin as 1 mm and up to 7 mm thick.

## 1000 W motor

With the powerful 1000 W motor of this Philips food processor you can adjust speed precisely to get desired results.

## XL feeding tube



The XL feeding tube takes whole fruits and vegetables so you don't need to pre-cut them anymore.

## XL 3.4 L bowl



The XL bowl allows for maximum volumes to be processed in one go: capacity for 2 l soup, 1.7 kg dough, 7 eggwhites.

## Compact 2-in-1 setup



Compact setup fits blender or bowl to save countertop space

# Specifications

## Technical specifications

**Blender jar capacity:** 1.5 L  
**Bowl capacity dry:** 3.4 L  
**Bowl capacity liquid:** 2 L  
**Bowl capacity flour:** 1000 g  
**Bowl capacity dough:** 1700 g  
**Speeds:** Variospeed  
**Safety:** Lid & bowl detection, mechanical 1.5 sec brake  
**Voltage:** 220-240 V  
**Frequency:** 50-60 Hz  
**Cord length:** 120 cm  
**Power:** 1000 W

## Accessories

**Number of inserts/discs:** 2  
**Reversible shredding disk:** For medium and fine shredding  
**Adjustable slicing disk:** For 1-7 mm slices of fruit & vegetables  
**Citrus press:** For pressing of citrus fruits  
**Kneading tool:** For kneading, heavy kneading, mixing dough, batter  
**Stainless steel chopping knife:** chopping, Beating, creaming, crumbling, cutting, folding in, mashing, mincing  
**Balloon beater:** Double beater for whipping, whisking, mixing and emulsifying  
**Break resistant blender:** blending, crushing, foaming, grinding, pureeing, homogenizing, liquidizing, milling, shaking, stirring  
[Recipe book](#)

## Design specifications

**Housing:** ABS  
**Knife holder, balloon beater:** POM  
**Disks, chopping blade:** Stainless steel  
**Speed knob:** Brushed aluminium  
**Kneading tool, citrus press:** PP  
**Function buttons:** Pulse, Ice  
**Bowl including lid and blender:** SAN  
**Pusher, inner pusher:** ABS, SAN  
**Color(s):** White

## General specifications

**Integrated cord storage**  
**Non-slip feet**

## Country of origin

China

