

PHILIPS

Bagless vacuum
cleaner

HomeCare



FC8256/01



Keep it out of sight!

Ultra-compact, with storage box

Thanks to its ultra-compact design, this vacuum cleaner is lightweight and easy to store away. A convenient storage box neatly stores the vacuum and other cleaning accessories after use. The cyclonic dustbin saves the use of a dust bag.

Easy storage of accessories in handy box

- Plastified carton box with accessory tray

High cleaning power

- 1400 Watt motor generating max. 200 Watt suction power

No dust bag required

- Cyclonic dustbin 1 liter

Highlights

Plastified carton box with accessory tray



This packaging is made of plastified carton to enhance the lifetime of usage when used for storage. It has a carton partition inside to store the hose separately from the vacuum cleaner and a carton tray to store the nozzle, tubes and accessories above the vacuum cleaner.

Cyclonic dustbin 1 liter



Cyclonic dustbin 1 liter

Specifications

Design

Color: Marina blue

Performance

Input power (max): 1400 W
Input power (IEC): 1200 W
Suction power (max): 200 W
Vacuum (max): 27 kPa
Airflow (max): 33 l/s
Noise level (Lc IEC): 85 dB

Filtration

Dust capacity: 1 l
Exhaust filter: AFS micro filter

Usability

Action radius: 9 m
Tube type: 3-piece plastic tube
Carrying handle: Top and front
Coupling: Conical
Park or storage assist: Back
Wheel type: Plastic
Cord length: 6 m

Nozzles and accessories

Standard nozzle: All-purpose nozzle
Accessories: Crevice tool
Accessories storage: In plastified carton storage box

Dimensions & weight

Weight: 3.7 kg

