



Saeco Talea
Super-automatic
espresso machine

- Touch
- Plus

RI9828/47

Cafè-enjoyment in elegance awaits you

Enjoy your full customized espresso

Talea standard line

Bean- to-cup customization

- Adjust coffee length, intensity, temperature and strength
- Patented adjustable espresso crema and body structure

Easy to use

- Delicious milk froth thanks to the classic milk frother
- Auto-lift drip tray for ultimate convenience
- Cup warmer
- Touch screen
- Ergonomic in day-by-day operations

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group

PHILIPS

Saeco, a Philips brand

 **Saeco**



Highlights

Coffe Customization



With Saeco you can always easily select the coffee length, intensity, temperature and strength you prefer. Your personal settings are memorized so you can enjoy your favourite coffee at the touch of a button.

SBS (Saeco Brewing System)



Saeco automatic espresso machine exclusively allows you to adjust your espresso's intensity, altering the crema and body structure as it is dispensed. Simply by turning the knob you can prepare the crema exactly according to your taste. A little knob that makes a big difference.

Cup warmer



This feature allows you to not only store your espresso cups and glasses right on the espresso

machine, it also pre-heats them letting the aroma unfold even better and guaranteeing a long-lasting crema

Auto-lift drip tray



Gaggia's patented automatically adjustable drip tray will make every cup size fit under your Espresso machine.

Touch screen

Touch screen user interface - amber color

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Ergonomy



Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments are directly accessible.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Specifications

Technical specifications

- Boiler material: Stainless steel (Inox)
- Power: 1400 W
- Voltage: 120 V
- Frequency: 60 Hz
- Cord length: 80 cm

Sustainability

- Automatic Stand-by Option

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor, Cup warmer

Weight and dimensions

- Product dimensions (L x D x H): 320 x 415 x

370 mm

- Product weight: 9.1 kg
- Coffee bean capacity: 250 gr
- Waste container capacity: 14 servings
- Water tank capacity: 1.7 L

Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle
- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Cup holding surface, Frontal access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank

Multi-Beverage

- Milk Variations: Frothing degree adaptor