

# PHILIPS

Handheld vacuum  
cleaner

3.6 V



FC6050/99



## Easy cleaning anywhere

Vacuum cleaner with precision nose piece

The specially designed Philips FC6050 (3.6 V) vacuum cleaner, cleans anywhere easily, thanks to its extended nose piece. The FC6050 has 3 powerful rechargeable batteries that give you the freedom of efficient cordless cleaning.

**Easily cleans in corners and along curves**

- Extended nose piece

**Cordless cleaning power wherever you want**

- Powerful rechargeable batteries

**Lasting suction power**

- 2-stage filter system prevents early clogging

**Easily cleans delicate surfaces and narrow spaces**

- Brush tool and crevice tool

# Highlights

## Extended nose piece



The Philips Mini Vac FC6050 series has a long, narrow nose especially designed for precision cleaning. The extended nose piece makes it easy to clean in corners and along curves.

## Powerful rechargeable batteries



The Philips Mini Vac's rechargeable battery gives you the freedom of cordless cleaning wherever you want.

## 2-stage filter system prevents early clogging



The Philips Mini Vac's 2-stage filtration system ensures that, once inside, dirt cannot escape. The first filter blocks most dirt, while the pleated, second filter traps the finer dust particles.

## Brush tool and crevice tool



The Philips Mini Vac comes with a number of accessories to tackle any job with ease. The soft brush attachment is gentle on delicate surfaces and the crevice tool lets you clean even those awkward, hard-to-reach places.

# Specifications

## Design

Color: Spicy orange

## Filtration

Dust capacity: 0.3 L

Filter type: Permanent washable

Filter system: 2-stage

## Performance

Airflow (max): 620 l/min

Battery voltage: 3.6 V

Charging time: 16-18 hour(s)

Noise level (Lc IEC): 77 dB

Runtime: 9 minute(s)

Suction power (max): 6.1 W

Vacuum (max): 1.9 kPa

## Weight and dimensions

Dimensions of A-box (LxWxH): 402 x 397 x 453 mm

Appliances per A-box: 6

Dimensions of packaging (LxWxH): 419 x 125 x 190 mm

Weight of product: 1.2 kg

