

PHILIPS

Steam generator
iron

PerfectCare Expert

Up to 6.5 bar pressure

320 g steam boost

Carry lock

1.5 l detachable water tank

GC9236/02



Carefree ironing, no setting required

Detachable water tank for easy filling

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.

Carefree ironing, no temperature setting required

- Iron everything from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board
- Tested and approved by independent textile experts

Fast and powerful ironing

- Ready to use in 2 minutes with unlimited refill
- Descale your appliance effectively and easily to prolong its lifespan
- New SteamGlide soleplate is Philips premium soleplate
- Up to 6 bar pressure
- 1.5 L detachable water tank, up to 2 hours of ironing
- Lock your iron securely to the base station
- Steam boost of up to 320 g



Highlights

Steam ready in 2 minutes



Steam is ready to use in 2 minutes and can be refilled at any time during ironing.

Easy De-calc



Ultra-long-lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend the lifetime of your steam generator iron. Your iron will remind you to de-calc with light and sound. When your appliance is cold, simply open the Easy De-Calc knob and collect the dirty water and limescale in a cup.

New SteamGlide soleplate



The new SteamGlide soleplate is the best Philips soleplate. Is extremely scratch resistant, glides excellently and is easy to clean.

Up to 6 bar pressure



The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing both faster and better. Steam power can be regulated to suit your needs.

1.5 L detachable water tank

The water tank can be removed to be refilled easily under the tap. The large filling hole makes refilling fast. Thanks to the 1.5 L water tank capacity, you can iron up to 2 hours continuously without any refills.

OptimalTEMP technology



Now you can iron everything from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with both the Advanced Smart Control Processor, which precisely controls the soleplate temperature so that you don't need to, and the powerful cyclonic steam chamber, which delivers consistent, powerful steam, making ironing easier and faster.

Safe rest



The innovative Philips OptimalTEMP technology guarantees no burns on all ironable fabrics. During ironing, there is no need to put your iron back on the base station; just leave the hot iron soleplate directly on the garments or cotton ironing board cover without an additional resting accessory. It will not damage any of your ironable garments, or the board. This makes your ironing easier, with less wrist effort.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer and reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.



[asimpleswitch.com](https://www.asimpleswitch.com)

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Fast and powerful crease removal

Soleplate: SteamGlide
OptimalTEMP technology
Steam boost: 320 g
Vertical steaming
Pressure: Up to 6
Steam tip
Power: 2400 W
Safe rest
Steam output control
Variable steam settings

Easy to use

Water tank capacity: 1500 ml
Filling and emptying water: Detachable water tank, Extra-large filling hole
Refill any time
Heat-up time: 2 min
Storage solution: Carry lock
Hose storage: Hose storage compartment
Cord storage: Cord storage compartment
Power cord length: 1.8 m
Cord freedom (swivel): 180 degree cord freedom

Hose length: 1.7 m

Safe for all fabrics: Even for delicates such as silks

Calc management

Suitable for tap water
Calc clean solution: Easy De-calc
Calc clean reminder

Technical specifications

Packaging dimensions: 30.5 x 33.5 x 49.1 cm
Product dimensions: 28.3 x 26.3 x 42.4 cm
Weight of iron: 1.2 kg
Weight of iron + base: 5 kg

