

PHILIPS

Bagless vacuum cleaner

EasyClean

1800W

HomeCare



FC8716/01



Take the effort out of cleaning

No bag required

The Philips EasyClean bagless vacuum cleaner is designed for those people who want a thorough cleaning result at minimal effort.

Easily removes dirt and dust

- 1800 Watt motor generating max. 300 Watt suction power

Clean air in your home

- Super Clean Air HEPA 12 filter, 99.5% filtration

Easy dust disposal

- Dust bucket can easily be removed and emptied

Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

Highlights

1800 Watt motor



Philips vacuum cleaner with 1800 Watt motor generating max. 300 Watt suction power to ensure a perfect cleaning result.

Super Clean Air HEPA 12 filter



This Super Clean Air HEPA 12 filter catches at least 99.5% of all harmful microscopic vermin that causes respiratory allergies.

Easy to empty dust bucket



The bagless vacuum cleaner has a transparent dust bucket that shows the dust removed from your floor and makes it easy to find back accidentally sucked up valuables.

TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

Specifications

Design

Color: Deep red

Filtration

Exhaust filter: Super Clean Air HEPA 12 filter

Filter type: Gore-Tex HEPA 10

Dust capacity: 2 L

Nozzles and accessories

Accessories included: Crevice tool, Small nozzle

Accessory storage: On handgrip

Standard nozzle: TriActive nozzle

Performance

Airflow (max): 34 l/s

Input power (IEC): 1600 W

Input power (max): 1800 W

Noise level (Lc IEC): 79 dB

Suction power (max): 300 W

Vacuum (max): 26.5 kPa

Usability

Carrying handle: Top and front

Tube coupling: Button

Power control: Electronic on appliance

Tube type: Metal lacquered 2-piece telescopic tube

Wheel type: Rubber

Action radius: 10 m

Cord length: 7 m

Weight and dimensions

Weight of product: 6 kg

