

PHILIPS

Food processor

Daily Collection

650 W

Compact 2 in 1 setup

2.1 L bowl

Accessories for + 25 functions

HR7628/01



Maximum variety of recipes, minimum effort

Create home made breads, cakes, drinks and more

This Philips Daily collection Food Processor has a compact design including a 2.1L bowl and 1.75 L blender and a variety of high performance accessories. Preparing delicious homemade food has never been so easy!

Powerful precision

- PowerChop technology for superior chopping performance

Reliably durable

- Break-resistant jar for intensive use

Easiest assembly, use and cleaning

- No mess from center of the bowl due to lack of inner shaft
- 40% larger feeding tube (compared to Philips HR7625)
- 650 Watt motor for powerful processing
- 2 speed settings and pulse for maximum control
- Dishwasher safe accessories

Maximum variety of recipes

- Emulsifying tool for cream and egg whites
- High performance stainless steel disc inserts
- Sharp and strong stainless steel S blade for chopping
- Up to 5 portions in one go



asimpleswitch.com

Highlights

PowerChop technology



PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

40% larger feeding tube



The new Philips Daily collection Food Processor comes with a feeding tube which is 40% larger than the previous HR7625 model, saving precutting time of fruits and vegetables

Dishwasher safe accessories



All accessory parts of your Philips food processor can be put on the top rack of your dishwasher for easy cleaning.

Break-resistant jar



A 1.75-liter break-resistant jar has a working capacity of 1 liter for up to up to 5 smoothie portions at once.

Powerful processing



This Philips Food Processor offers a powerful motor providing power and control to prepare all your favorite recipes.

Emulsifying tool



The perfect tool for whipping, whisking or emulsifying eggs or whipped cream. For best volume increase and fluffiness, use the low speed setting. Creating delicious desserts or mayonnaise has never been easier!

No mess from center of bowl



Unlike other cheaper food processors, this Philips Food Processor lacks an inner chimney shaft in the middle of the bowl. This means that soups and other liquids won't leak from the middle of the bowl, keeping your food processor and kitchen counter clean! It even makes assembling your appliance much easier – simply click your tool holder in place in the bowl, guided by the form fitting couplings.

2 speed settings and pulse



For best results, use the low speed setting (speed 1) to whip cream, beat eggs, create pastries and bread dough. The higher speed setting (speed 2) is well suited to chop onions and meats, blend soups and smoothies or shred, slice, grate or rasp vegetables.



[asimpleswitch.com](https://www.asimpleswitch.com)

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

General specifications

Number of slicing disks: 3

Number of speed settings: 2 + pulse

Product features: Integrated cord storage,
Non-slip feet, Pulse

Accessories

Included: Blade unit S-blade, Chopping knife,
Coarse shredding tool, Coarse slicing tool,
Emulsifying tool, Fine shredding tool, Fine
slicing tool, Jar

Technical specifications

Frequency: 50/60 Hz

Power: 650 W

Voltage: 220-240 V

Capacity bowl: 2 L

Capacity jar: 1.75 L

Cord length: 1.0 m

RPM blender (max): 21000 rpm

RPM bowl (max): 1900 rpm

Working capacity bowl: 1.5 L

Working capacity jar: 1.0 L

Design

Color: White

Finishing

Material accessories: Stainless steel

Material jar: Plastic SAN

Material of main body: Plastic ABS

Service

2-year worldwide guarantee

Sustainability

Packaging: > 90% recycled materials

User manual: 100% recycled paper

