

PHILIPS

Blender

Daily Collection

400 W

1.5 L Plastic Jar

with filter, mill and chopper

5 star serrated blade

HR2104/43



Fresh smoothie and food made easy

With extra strong power and blade

This Philips Daily Collection Blender offers a 400 W motor, 1.5 l jar and a serrated 5star blade combined to create perfect end results for your smoothie and food preparation. It makes your tough blending made easy!

For perfect smoothie and food preparation

- Strong 400 W motor
- Break-resistant plastic jar
- Serrated 5star blade for effective blending and mixing
- Multiple speeds for soft and hard ingredients
- Blender filter for clear juice and soy bean milk
- Mini chopper for chopping soft ingredients
- Mill for grinding hard ingredients
- Pulse for better mixing and blending

Easy to use

- Lock indicator for ready to use
- Improved pouring by new spout
- All parts are dishwasher safe

Quality guaranteed

- 2 year guarantee



asimpleswitch.com

Highlights

400 W motor

Strong 400 W motor for blending and mixing easily.

Break-resistant plastic jar

Avoid breakages with this reinforced plastic jar. The 1.5-liter jar has a working capacity of 1.25 liters.

Serrated 5star blade

The newly designed blade will blend and cut the ingredients effectively and make a perfect smoothie for you and your family.

Multiple speeds

Blend at different speeds and to different degrees with a choice of setting.

Filter



Easy blend soy bean milk or fruit juice pips and seeds

Mini chopper

Use mini chopper accessory to chop any soft ingredients like herbs, chili, onion and meats.

Mill

Use mill accessory to grind any hard ingredients like coffee beans, nuts and dried chili and peppers.

Pulse for mixing and blending

You can use "Pulse" mode to control blending degree and time conveniently.

Lock indicator

This simple and easily recognizable lock indicator will let you know when the appliance is ready to use with safety.

New spout design

New spout design will prevent leakage after pouring to the glass.

All parts are dishwasher safe



All removable parts can be cleaned in the dishwasher.

2 year guarantee



With 2 years world-wide warrantee.

Specifications

Design specifications

Material housing: PP
Material blade: Stainless steel
Material blender jar: SAN
Color(s): Lime yellow

General specifications

Cord storage
Non-slip feet
Speed setting: 2 and pulse

Technical specifications

Power: 400 W
Effective jar capacity: 1.25 L
Frequency: 50/60 Hz
Capacity mini chopper: 120 ml
Capacity mill: 120 ml
Voltage: 220-240 V
Cord length: 0.85 m
Max Jar Capacity: 1.5 l

Accessories

Filter
Mill
Mini chopper



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.