

PHILIPS

Vacuum cleaner
with bag

Performer

2000W

500W suction power

HEPA 13 washable filter

FC9170/07



The highest suction power ever

500 Watt suction power for effortless cleaning

Philips Special Edition Performer FC9170/07 vacuum cleaner celebrates 40 years of Floor Care experience. In addition to our new Titanium color, we are celebrating with a handy 5-piece car cleaning kit, added as gift to every S.E. Performer.

Superior cleaning

- 2200 Watt motor generating max. 500 Watt suction power

Highly efficient anti-allergy system

- HEPA AirSeal plus HEPA 13 filter
- ECARF Seal of Quality for trusted results

Long lasting dust pickup

- s-bag in XXL 4 liter capacity for long-lasting performance

Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

Enjoy the comfort of a clean car

- Gift bag with car cleaning kit

Highlights

Powerful cleaning



Highly efficient 2200 Watt motor generates max. 500 Watt suction power for perfect cleaning results.

HEPA AirSeal, HEPA 13 filter



This Philips vacuum cleaner has been designed in such a way that all the air taken in is passed through the washable HEPA 13 filter (99.95% filtration) before it is exhausted. No escape is possible.

s-bag in XXL 4 liter



This large dust bag capacity allows you to make optimal use of your dust bag, which means you have to change your dust bag less frequently.

TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

Car Cleaning Kit



Every Special Edition Performer comes with a gift bag containing a car cleaning kit. This complete set of tools is of great use while cleaning your car. For different surfaces in your car special nozzles are included in the kit. All nozzles can be easily attached to your Special Edition Performer. Tools include a microfibre cleaning glove, an adjustable brush, an extra long crevice tool, a universal nozzle, and a special upholstery nozzle.

Specifications

Design

Color: Titanium

Filtration

Dust bag type: s-bag

Exhaust filter: Ultra Clean Air HEPA 13 washable filter

Dust capacity: 4 L

HEPA Air Seal

Nozzles and accessories

Standard nozzle: TriActive nozzle

Accessories included: Brush, Crevice tool, Small nozzle

Accessory storage: On handgrip

Performance

Airflow (max): 47 l/s

Input power (IEC): 2000 W

Input power (max): 2200 W

Noise level (Lc IEC): 78 dB

Suction power (max): 500 W

Vacuum (max): 34 kPa

Usability

Tube type: Metal 2-piece telescopic tube

Carrying handle: Top and front

Dust full indicator

Clean Comfort cassette

Tube coupling: Easy release

Power control: Electronic on appliance

Wheel type: Rubber

Action radius: 12 m

Cord length: 7 m

Weight and dimensions

Weight of product: 6.3 kg

Dimensions of product (LxWxH): 500 x 320 x 280 mm

