

PHILIPS

Kitchen Machine

Avance Collection

900 W

7 speeds and pulse

Easy 6-in 1 set up



HR7958/00

Unbeatable results, easier than you think

Cake, bread, pizza, cookies, smoothies, soups and more

Presenting the all new Philips Kitchen Machine - unbeatable performance and versatility, easier than you thought!

Unbeatable kneading, mixing, whisking results

- Powerful 900 W motor for consistent, unbeatable results
- Planetary Mixing Action for thoroughly mixed ingredients
- 7 speeds and pulse for maximum control
- 4L metal bowl for upto 1300gms of dough
- Metal kneading hook, whisk and beater, designed to perform

Versatile, high performing accessories

- 1.25L blender jar with easy to clean detachable blade
- 1.5L Food processor that slices, chops, shreds, granulates
- Citrus press for fresh juice in minutes
- Grinder mill
- Self feeding meat mincer

Easier than you thought

- Unique open arm for full bowl access, easier to attach tools
- Easier to clean with rounded edges, covered hinge



asimpleswitch.com

Highlights

Powerful 900 W motor



Powerful 900 W motor for consistent, unbeatable results.

7 speed control and pulse



Multiple speeds and pulse gives maximum control for unlimited variety of recipes.

1.25L blender jar



Based on world class, leading Philips blender technology, high performing blender attachment with a 4 star blade blends fruit, purees vegetables, crushes ice effortlessly. So you can enjoy smoothies, sauces, dips or baby food in minutes.

Planetary Mixing Action



Planetary Mixing Action allows the kneading, mixing and whisking tools to move in a unique backwards and forwards movement rather than just in a simple circle, reaching all corners of the bowl, and resulting in the smooth, thoroughly mixed ingredients.

Strong metal bowl tools



Metal kneading hook, beater and whisk are easy to lock into place with a simple twist. Specially designed kneading hook mimics kneading by hand to ensure smooth, lump free dough.

1.5L Food processor



Easy to attach food processor bowl with dedicated discs for slicing, chopping, shredding or granulating all variety of ingredients from vegetables to nuts to cheese.

4L metal bowl with handle



Large, robust 4L metal bowl can comfortably knead upto 1300gms of dough so you can to make upto 4 12" pizzas or 2 loafs of bread in one go. The metal handle makes it easy to carry and pour. While the splash guard cover prevents splashing when in use.

Unique open arm for easier use



The open arm swings up in a practical position so you can easily attach and detach the bowl tools. It can be closed again with a simple one hand push. The open arm also offers you full bowl access, a practical feature when checking consistency or adding ingredients.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Accessories included

1.2L blender
1.5L Food processor with discs
4L metal bowl
Citrus press
Grinder Mill
Meat mincer
Metal kneading hook

Design specifications

Color(s): White and grey
Housing material: ABS
Material bowl tools: Metal
Material bowl: Stainless steel

General specifications

Speeds: 7 + pulse

Technical specifications

Power: 900 W

