

PHILIPS

Food processor

Pure Essentials
Collection

1000 W

Compact 2 in 1 setup

3.4 L bowl



HR7774/30



Effortless excellence

Powerful food processor with bigger tube and bowl

This state-of-the-art food Philips processor has some of the most advanced technologies. Its versatility is ensured by 7 accessories which easily perform 30+ functions.

Powerful precision

- 1000 W motor
- Ice and pulse functions for chopping and crushing
- Adjustable blade for slices between 1-7 mm

Effortlessly easy

- 7 accessories to easily perform 30+ functions
- XL feeding tube takes whole fruits or vegetables
- Up to 7 portions in 1 go with the XL bowl
- One touch (dis)assembly

Stylishly compact

- Compact 2-in-1 setup saves countertop space

Reliably durable

- Dishwasher safe accessories

Highlights

30+ functions



The – dishwasher safe – accessories are a kneading tool for mixing batter and for heavy kneading. A stainless steel chopping knife to prepare meat and vegetables. Two metal disks to handle medium and fine shredding and grating. Break resistant blender of 1.5l for blending, crushing up to stirring different ingredients. A citrus press for pressing citrus fruits. And a balloon beater for whipping and whisking and handling light batter.

Adjustable slicing blade

With the adjustable slicing blade, you can make slices as thin as 1 mm and up to 7 mm thick.

1000 W motor

With the powerful 1000 W motor of this Philips food processor you can adjust speed precisely to get desired results.

XL feeding tube



The XL feeding tube takes whole fruits and vegetables so you don't need to pre-cut them anymore.

XL 3.4 L bowl



The XL bowl allows for maximum volumes to be processed in one go: capacity for 2 l soup, 1.7 kg dough, 7 eggwhites.

Compact 2-in-1 setup



Compact setup fits blender or bowl to save countertop space

Specifications

Technical specifications

Blender jar capacity: 1.5 l

Bowl capacity dry: 3.4 l

Bowl capacity liquid: 2 l

Bowl capacity flour: 1000 g

Bowl capacity dough: 1700 g

Speeds: Variospeed

Safety: Lid & bowl detection, mechanical 1.5 sec brake

Voltage: 220-240 V

Frequency: 50-60 Hz

Cord length: 120 cm

Power: 1000 W

Accessories

Number of inserts/discs: 2

Reversible shredding disk: For medium and fine shredding

Adjustable slicing disk: For 1-7 mm slices of fruit & vegetables

Citrus press: For pressing of citrus fruits

Kneading tool: For kneading, heavy kneading, mixing dough, batter

Stainless steel chopping knife: chopping, Beating, creaming, crumbling, cutting, folding in, mashing, mincing

Balloon beater: Double beater for whipping, whisking, mixing and emulsifying

Break resistant blender: blending, crushing, foaming, grinding, pureeing, homogenizing, liquidizing, milling, shaking, stirring

Recipe book

Design specifications

Housing: ABS

Knife holder, balloon beater: POM

Disks, chopping blade: Stainless steel

Speed knob: Brushed aluminium

Kneading tool, citrus press: PP

Function buttons: Pulse, Ice

Bowl including lid and blender: SAN

Pusher, inner pusher: ABS, SAN

Color(s): White

General specifications

Integrated cord storage

Non-slip feet

Country of origin

China

