# **PHILIPS**

Pressurised steam generator

**InstantCare** 

120 g/min steam

260 g steam boost

**ECO** 



GC7541/02



# Fast and powerful ironing

Two minute quick start, refill any time

Created to speed up ironing from start to finish, the Philips InstantCare is ready to use in 2 minutes. The power of the pressurised steam speeds up ironing by penetrating deeper into the fabrics to remove the creases.

## Fast and powerful ironing

- · Continuous steam up to 120 g/min
- $\cdot$  Up to 5.2 bars of steam pressure
- Steam boost up to 260 g for tough wrinkle removal

## **Comfortable ironing**

- · SteamGlide soleplate is Philips premium soleplate
- · Lightweight iron for effortless ironing
- · 3 Safety Auto Off triggers

#### Easy to use

- Start quickly: less than 2 minutes start-up time
- · Refill the water tank at any time, even during ironing
- · Permanent anti-calc tablets inside delay scale build up
- · Save 30% energy and 40% water consumption

# Highlights

#### Continuous steam up to 120 g/m



The Philips iron has a continuous steam output of up to 120 g/min thanks to the small amounts of water that are pumped into the boiler each time. For perfect and fast crease removal.

Up to 5.2 bar

5.2 bar

Double your ironing speed with pressurised steam. Pressurised steam penetrates deep into fabrics, making your ironing fast and easy, even on difficult fabrics.

# SteamGlide soleplate



The SteamGlide soleplate is the best Philips soleplate for your steam iron. It has great scratch resistance, glides excellently and is easy to clean.

### Lightweight



The iron is only 1.2 kg making ironing easy and effortless.

#### **Anti-calc Tablets**



Permanent anti-calc tablets delay the formation of scale build up ensuring better protection for your system iron

Quick start: < 2 minutes



2 mins start

This system iron is ready to use in less than 2 minutes.

### **ECO** setting



Save 30% energy and 40% water consumption by selecting the eco-setting. The eco-setting offers the most energy efficient way to obtain perfect ironing results.

#### Refill the water tank any time



The separate water tank allows you to re-fill the water tank any time, even during ironing, without waiting.

### **Safety Auto Off**



Iron shuts off automatically when the iron is held still for 30s on its soleplate, lying on its side for 30s or standing on its heel rest for 8 minutes.

# Specifications

#### Fast and powerful crease removal

Soleplate: SteamGlide Steam output

Continuous steam output: 120 g/min

Steam boost: Up to 260 g

Vertical steam
Pressure: Up to 5.2
Variable steam settings

Steam tip Power: 2400 W Easy to use

Water tank capacity: 1000 ml

Filling and emptying water: Extra large filling

hole

Refill any time Heat-up time: 2 min Safety auto off Hose storage: Hose clip Power cord length: 1.8 m

Cord freedom (swivel): 180 degree cord

freedom

Hose length: 1.7 m

**Sustainability** 

ECO setting: 30% energy reduction

**Calc management** 

Suitable for tap water

Calc clean solution: Anti-calc tablets and

rinsing

**Technical specifications** 

Voltage: 220 - 240 V

Product dimensions: 42.9 x 40 x 20.6 cm

Weight of iron: 1.2 kg Weight of iron + base: 4.5 kg

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-02-08 Version: 5.0.1

EAN: 08 71010 36460 82

www.philips.com

