

PHILIPS

Steam generator
iron

PerfectCare
Performer

Max 6 bar pump pressure

Up to 350 g steam boost

1.8 L detachable watertank



GC8711/20



Powerful continuous steam for ultra faster ironing

1.8 L detachable water tank

Philips PerfectCare Performer steam generator iron ensures a true simple, powerful, and no burn ironing experience. The powerful continuous steam penetrates deeply and continuously into the fibre to remove creases easily.

Carefree ironing, no temperature setting required

- Iron from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board

Fast and powerful ironing

- Max 6 bar pump pressure
- CompatProVelocity Steam Engine: all the time continuous steam
- Continuous steam up to 120 g/min
- Ready to use in 2 minutes with unlimited refill
- Lighter weight steam generator from Philips
- 1.8 L detachable water tank, up to 2 hours of ironing
- Tap water friendly, refill anytime during ironing
- Smart Calc clean system with sound&light Calc Clean reminder
- Saving energy with ECO mode



asimpleswitch.com

Highlights

1.8 L detachable water tank



The watertank can be removed to be refilled easily under the tap. The large filling hole makes the refilling fast. Thanks to the 1.8 L watertank capacity, you can iron up to 2 hours continuously without any refills.

ProVelocity Steam Engine

Water is transferred from the water tank to the iron by a high pressure pump. A lot of water travels inside of steam chamber at very high speed. It enables very powerful and constant steam all the time to come out from the soleplate without water condensation;

Continuous steam



The more steam, the faster the ironing. The unique technology in a Philips steam generator iron generates powerful steam making ironing easier, better and faster.

Energy saving



By using the ECO mode, with reduced amount of steam, you can save energy without compromising on the ironing results.

Lighter weight steam generator

Thanks to the revolutionary ProVelocity technology, we made your steam generator iron more compact than ever before. The compact steam generator fits easily on your ironing board making your ironing more convenient. In addition, your steam generator takes much less storage space.

Max 6 bar pump pressure



The more steam, the faster the ironing. Powerful continuous steam is generated which penetrates deep inside the garments making ironing faster and better. Steam amount can be regulated to fit your needs.

OptimalTEMP technology



"Now you can iron from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust temperature 2) Compact ProVelocity steam engine delivers more steam for ironing faster. It enables compact design of your steam generator for easier storage"

Refill tap water any time



Your steam generator iron is designed to use tap water. While ironing, when you run out of water in the watertank, you can refill it easily without waiting or turning your appliance off.

Safe rest



The Philips innovative OptimalTEMP technology guarantees no burn on all ironable fabrics. During ironing, no need to put your iron back to the base station, just leave the hot iron soleplate directly on the garments or cotton ironing board cover without additional resting accessory. It will not damage any of your ironable garments, neither the board. This makes your ironing easier with less wrist efforts.



[asimpleswitch.com](https://www.asimpleswitch.com)

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Technology

For all ironable fabrics
No burns
OptimalTEMP technology
ProVelocity steam engine
Smart Control Processor

Fast crease removal

Continuous steam: Up to 120 g/min
Power: 2600 W
Pressure: Max 6 bar pump
Ready to use: 2 min
Steam boost: Up to 350 g
Steam-on-demand
Variable steam levels
Vertical steam

Easy to use

Safe on all ironable fabrics: Even delicates like silk
Soleplate gliding performance: 5 stars
Soleplate name: SteamGlide Plus
Detachable water tank
Hose length: 1.6 m
Power cord length: 1.8 m
Precision steam tip
Ready to use: Light indicator, Sound indicator
Refill any time during use
Soleplate scratch resistance: 4 stars

Scale management

Descaling and cleaning: Smart Calc Clean
Descaling reminder: Light, Sound, Yes

Storage

Carry lock: For transportation and safety
Cord storage: Velcro fix, Yes
Hose storage: Hose storage compartment

Size and weight

Weight of iron: 1.22 kg
Weight of iron + base: 3.2 kg
Product dimensions (WxHxL): 22 x 24 x 37 cm

Guarantee

2 year worldwide guarantee

Green efficiency

Energy saving mode
Product packaging: 100% recyclable
User manual: 100% recycled paper

