

PHILIPS

Steam generator
iron

SpeedCare

Max 4.3 bar pump pressure

1.2-l fixed water tank



GC6603



Faster and easier ironing**

with 2 times more steam** than a steam iron

The Philips SpeedCare steam generator delivers more steam than a steam iron, helping you to speed up your ironing. Enjoy more quality time with your family thanks to the reduced ironing time with the Philips SpeedCare steam generator iron.

Fast and powerful ironing

- Continuous steam up to 95 g/min
- Ready to use in 2 minutes with unlimited refill
- Triple precision tip for optimal control and visibility
- Ceramic soleplate for better gliding performance
- Smart Calc cleaning system with a sound and light cleaning reminder
- 1.2-l water tank and refill at any time during ironing
- Compact size and light weight for easy storage
- Max 4.3 bar pump pressure

Highlights

Max 4.3 bar pump pressure

The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing both faster and better. Steam power can be regulated to suit your needs.

Smart Calc cleaning system

The Smart Calc cleaning system is an integrated descaling and cleaning function that protects your steam generator iron. After around 10 hours of ironing, your steam generator iron will remind you to perform the Calc cleaning process with a sound and light notification. The iron conveniently rests on the Calc container as it collects the dirty water, so you don't have to strain to hold the iron during the process. After all the water has been collected in the container, your steam generator iron is ready to use again.

Steam ready in 2 minutes

Steam is ready to use in 2 minutes and can be refilled at any time during ironing.

Compact size and light weight

Thanks to the revolutionary ProVelocity technology, we made your steam generator iron more compact than ever before. The compact steam generator fits easily on your ironing board making your ironing more convenient. In addition, your steam generator takes much less storage space.

1.2-l water tank

The SpeedCare steam generator has a 1.2-l water tank capacity to allow you to iron for over an hour. It helps to reduce the number of refills required for large laundry loads. The

technology will also allow you refill the water tank during ironing without the appliance cooling down for 2 hours while it is waiting to be refilled.

Triple precision tip

The tip of this Philips iron is precise in 3 ways: it has a pointed tip, button groove and a sleek nose design. The triple precision tip enables you to reach even the most tricky areas, e.g. around the buttons or between the pleats.

Ceramic soleplate



Ceramic soleplate is scratch-resistant, glides well and is easy to clean.

Continuous steam



The more steam, the faster the ironing. The unique technology used in the Philips steam generator iron produces powerful steam, making ironing quicker, easier and better.

Specifications

Accessories

Calc Clean container

Calc management

Calc clean reminder

Calc clean solution: Smart Calc Clean

Filtered water recommended

Suitable for tap water

Easy to use

Cord freedom (swivel): 180 degree cord freedom

Cord storage: Cord clip

Heat-up time: 2 min

Hose length: 1.6 m

Hose storage: Hose storage compartment

Power cord length: 1.8 m

Refill any time

Ultra-light and comfortable

Water tank capacity: 1200 ml

Filling and emptying water: Extra-large filling hole

Fast and powerful crease removal

Continuous steam output: 95 g/min

Power: 2400 W

Soleplate: Ceramic

Steam output control

Vertical steaming

Pressure: Max 4.3 bar pump pressure

Technical specifications

Voltage: 220 - 240 V

Packaging dimensions: 26.4 x 30.3 x 40.4 cm

Product dimensions: 19.8 x 21.7 x 34.6 cm

Weight of iron: 1.1 kg

Weight of iron + base: 2.6 kg

Service

2-year worldwide guarantee

