



**Saeco Exprelia Evo
Super-automatic
espresso machine**

- Brews 7 coffee varieties
- Integrated milk jug & frother
- Steel Black
- 5 step adjustable grinder



HD8855/47

Experience the fine art of making coffee with the hygiene-proof milk jug certified by VDE

With the Saeco Exprelia Evo, aspiring coffee experts can experience the thrill of preparing a cup as professionals would, with the ability to customize multiple drinks and the guarantee of a perfect hygiene

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Hygienic milk frothing thanks to automated dual cleaning

A variety of coffees customized to your taste

- Enjoy a crema layer as you like it with a twist of a knob
- Fine-tune the coffee's richness with adjustable grinders
- Customize and save strength, length and milk foam settings

Advanced technology designed for coffee perfection

- Extract maximum flavor with the 100% ceramic grinders
- Silky foam at one touch with Double Chamber milk technology
- Milk specialties without the wait thanks to a double boiler

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

PHILIPS

Saeco, a Philips brand



Highlights

Automatic dual cleaning carafe



This Saeco espresso machine comes with a fully automated dual clean function for its milk carafe. The dual cleaning uses two independent steam cycles to swiftly rinse your milk carafe after each coffee drink you prepare, for a fresh milk drink everytime. Hygienic milk frothing was never this easy.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene. Descaling has never been so easy!

Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee or milk frothing temperatures, this Saeco fully automatic espresso machine guarantees professional performance and speed everytime. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous without waiting.

100% Ceramic grinders



The robust 100% ceramic grinders guarantee a moment of pure coffee indulgence for years to come. The ceramic material creates the ideal grind, which allows the water to flow through steadily, extracting the purest essence of the beans. And unlike other 'regular' grinders', the ceramic material prevents the coffee from overheating and tasting burnt.

Refine crema and body quality



Enjoy a crema layer just the way you like it and discover a wide spectrum of tastes, all with the twist of a knob! You control the coffee flow and brew pressure to vary the body and thickness of the crema with one easy move. Turn it left for a luxurious, thick crema layer and an intense and full bodied espresso; Or turn it right for a smooth, lighter tasting coffee with less crema.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Specifications

Country of origin

- Made in: Italy

General specifications

- Suitable for: Whole coffee beans, ground coffee powder
- Cups at the same time: 2
- Customizing per drink: Adjustable coffee strength
- Ease of cleaning & maintenance: Automatic de-scaling cycle, Automatic rinse cycle, Removable brewing group, Dishwasher-safe parts, Automatic carafe cleaning
- Ease of use and comfort: Adjustable spout, Removable water tank, Removable drip-tray, Display
- Special functions: Automatic milk frother, Integrated carafe, Pre-brewing, Steam option, Ceramic grinder, Crema adjustment knob, Manual milk frother Pannarello, Hot water option
- Type of boiler: Stainless steel boiler
- Type of carafe: Basic carafe
- Type of display: LCD
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato

Service

- 1-year guarantee

Technical specifications

- Capacity bean container: 300 gr
- Capacity milk carafe: 500 L
- Capacity waste container: 11 servings
- Capacity water tank: 1.5 L
- Cord length: 0.8 m
- Frequency: 60 Hz
- Max. cup height: 152 mm
- Pump pressure: 15 bar
- Voltage: 120 V
- Water boilers: 2

Weight and dimensions

- Dimensions of product (WxDxH): 245 x 360 x 420 mm
- Weight of product: 16.1 kg

Design

- Color: Black, Stainless steel

Finishing

- Material boiler: Stainless steel (Inox)
- Material of main body: Stainless steel
- Material water tank: Plastic

Sustainability

- Power consumption brewing: 1400 W