

# PHILIPS

Variety rice cooker

Daily Collection

4L

HD3025/03



## Optimal temperature settings for tasty meals from oats, rice and buckwheat

Philips' new multicookers with smart temperature control ensures easy cooking of favorite dishes.

### Smart and automatic cooking

- Automatic rice and congee cooking
- 3D heating for even heating and more effective warm keeping
- Automatic keep warm keeps rice fresh for 12 hours
- 1.5mm 5-layer inner pot for even heating, cooks rice tastier

### Easy to operate

- One touch button for easy control

### The ultimate in convenience

- Easy-to-clean detachable inner lid design
- Golden coating ensures inner pot durable and non-stick.
- Dishwasher friendly & non-stick inner pot
- Easy-to-read water level indicator
- Detachable power cord for convenient storage.
- Stainless steel outer shell for easy cleaning

# Highlights

## Golden coating

Golden coating ensures inner pot durable and non-stick.

## One touch button

One press button to control cook or keep warm, with clear light on the panel to show cooking status

## 3D heating system



There is heating system surround the rice cooker, including heater assembly on the top, heater assembly all around and main heater assembly on the bottom. 3D heating system for even heating, more effective warm keeping and better baking result

## Automatic 12 hours keep warm



Use the keep warm function to keep rice warm for a longer period of time. When the cooking process is finished, the rice cooker automatically switches to the keepwarm mode

## Easy-to-clean



Easy-to-clean detachable inner lid design.

# Specifications

## General specifications

Nutritional keep warm keeps rice fresh for 12 hrs

Detachable and washable inner lid

Dish washer safe inner pot

Easy-to-clean non-stick inner pot

Spillover prevention vent

Detachable power cord for convenient storage

## Design specifications

Materials of main body: SUS430

Color(s): Silver Metallic

Color of control panel: Grey

Dimensions (L x W x H): 269x269x233 mm

## Accessories

Spatula

Soup scoop

Plastic steam tray

Measuring cup

## Technical specifications

Capacity: 4/8 Litres / cups

Cord length: 1.2 m

Voltage: 220 V

Frequency: 50 Hz

Wattage: 650 W

