



40% more dust pick-up for a better clean

With PowerCyclone technology and AeroSeal nozzle

The new Philips PowerPro FC8764/01 bagless vacuum cleaner picks up more dust in one go, so your floor gets cleaner with fewer strokes. You can therefore spend more time doing the things you really enjoy.

More dust pick-up for faster cleaning

- PowerCyclone 5 technology separates dust and air in one go
- Powerful 2100 Watt motor for excellent cleaning results
- AeroSeal nozzle captures more dust and fluff per stroke

Extra long reach for convenient cleaning

• More cleaning with less effort

Easy to clean

Advanced dust container design for hygienic emptying

Highlights

AeroSeal nozzle



The AeroSeal nozzle captures more dust and fluff per stroke thanks to the special designed soleplate. It gently opens up the carpet to remove the dust deep down. Thanks to the optimal sealing the dust is transported into the cyclone with maximum airflow.

2100 Watt motor



This powerful 2100 Watt motor generates max. 370 Watt suction power for excellent cleaning results.

Easy to empty dust container



The dust container is carefully designed to dispose collected dirt without creating a dust cloud. It is one-hand operated and thanks to its

unique shape and smooth surface, you can easily control the emptying of the dust container.

10 m action radius



10 m action radius for cleaning with less effort.

PowerCyclone 5 Technology



PowerCyclone 5 technology maximizes airflow and performance by separating dirt from air in one go. It delivers remarkable cleaning results through highly efficient steps: 1) Air enters fast into the PowerCyclone thanks to the air inlet design. 2) The curved airpass quickly accelerates the air in the cyclonic chamber to separate the dust from the air. 3) The optimized exit blades separate dirt from the cyclone and into the dust bucket.

FC8764/01

Specifications

Design Color: Deep black

Filtration

Exhaust filter: EPA 12 filter Motor filter: Lifetime washable filter Dust capacity: 2 L HEPA Air Seal

Nozzles and accessories

Accessories included: Brush, Crevice tool, Small nozzle Accessory storage: On tubeclip Standard nozzle: AeroSeal nozzle

Performance

Airflow (max): 38 l/s Input power (IEC): 1800 W Input power (max): 2100 W Noise level (Lc IEC): 80 dB Suction power (max): 370 W Vacuum (max): 34 kPa

Sustainability

Packaging: > 90% recycled materials User manual: 100% recycled paper

Usability

Carrying handle: Top and front Tube coupling: Easy release Power control: Electronic on appliance Tube type: Metal 2-piece telescopic tube Wheel type: Rubber Action radius: 10 m Cord length: 7 m

Weight and dimensions

Weight of product: 5.5 kg Dimensions of product (LxWxH): 440 x 300 x 290 mm

© 2019 Koninklijke Philips N.V. All Rights reserved. Issue date 2019-03-15 Version: 14.2.1



* * Dust pick-up results compared to the top selling bagless vacuum cleaner in Europe, tested on average by external test institute according to DIN EN 60312/11/2008 on carpet, October 2011

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

www.philips.com