



Saeco Intuita
Super-automatic
espresso machine

- Classic Milk Frother
- Black

HD8750/13

Espresso from fresh beans

Select your aroma with this espresso machine

Saeco Intuita espresso machine offers you the possibility to taste freshly ground espresso at the touch of a button, aroma selection, easy to use, easy to customize and easy to clean

Authentic Italian coffee perfection

- Delicious milk froth thanks to the classic milk frother
- Coffee without waiting thanks to the quick heat boiler
- Coffee without burnt taste thanks to 100% ceramic grinders

Set the beverages to suit your taste

- Save your favorite coffee length and strength
- Play with the coffee's richness with our adjustable grinders
- Avoid heat loss and fit every cup with our adjustable spout

Ease of cleaning and maintaining

- Always a clean machine thanks to automatic circuit cleaning
- Easy cleaning thanks to removable brewing group
- Easy cleaning thanks to dishwasher-safe parts

PHILIPS

Saeco, a Philips brand

 **Saeco**

Highlights

Automatic circuit cleaning



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now

you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a "Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Saves coffee length & strength



You will always get a perfect cup of espresso brewed according to your personal preference, thanks to our memo function which allows you to adjust the coffee length and strength to suit your taste. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic cleaning.

Specifications

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse
- Usage: Adjustable coffee dispenser, Rapid steam, Removable brewing group, Normal / long espresso option

Weight and dimensions

- Product dimensions (L x D x H): 256 x 440 x 340 mm
- Coffee bean capacity: 300 gr
- Waste container capacity: 10 servings
- Water tank capacity: 1.5 L
- Maximum cup height: 152 mm
- Product weight: 8 kg

Features

- Pannarello: Plastic
- Simultaneous brewing
- Brita Filter compatible: Optionable

Design

- Colour: Mat Black
- Materials and finishing: Plastic

Technical specifications

- Cord length: 80 cm
- Power: 1850 W
- Number of water boilers: 1 boiler
- Country of origin: Designed in Italy, Made in Europe
- Removable brewing group
- Supported coffee types: Whole coffee beans
- Water pressure in pump: 15 bar (perfect espresso)