

PHILIPS

Food processor

Viva Collection

750 W

Compact 3 in 1 setup

2 L bowl

Accessories for + 28 functions



HR7762/90



Maximum variety of recipes, minimum effort

Create home made cakes, gratins, salads and more

This Philips Food Processor has a 3 in 1 compact set-up with a 2 L bowl, blender and grinder mill. It also has 4 stainless steel discs enabling you to create a variety of your favorite recipes. Accessory storage included.

Powerful precision

- 750 W motor for powerful processing
- PowerChop technology for superior chopping performance
- 2 speed settings and pulse for maximum control
- Accessories to easily perform 28+ functions

Effortlessly easy

- Color coded accessory and speed combinations
- Form fitting couplings and tools for easy assembly
- Practical accessory storage included

Reliably durable

- Stainless discs to slice, shred, granulate, cut French fries
- Dishwasher safe accessories
- Break-resistant jar for intensive use

Maximum variety of recipes

- Up to 5 portions in one go



asimpleswitch.com

Highlights

Powerful processing



This Philips Food Processor offers a powerful motor with 2 speeds and pulse, providing power and control to prepare all your favorite recipes.

PowerChop technology



PowerChop

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

Accessories for 28+ functions

The - dishwasher safe - accessories are a kneading tool to mix and knead batter and dough. A stainless steel chopping knife to prepare meat and vegetables. Various disc inserts to handle shredding and grating. Break resistant blender of 1L for blending, crushing and stirring different ingredients. An emulsifying disc to prepare food like whipped cream and mayonnaise. A chopper mill to grind e.g. coffee beans

Up to 5 portions in one go



The generous 2.1L bowl (1.5 L working capacity) enables you to blend up to 5 portions of soup in one go.

Break-resistant jar



A 1.75-liter break-resistant jar has a working capacity of 1 liter for up to up to 5 smoothie portions at once.

Form fitting couplings & tools

This Philips food processor is designed to be very easy to assemble. Its parts simply click together thanks to the clever form fitting design of the accessories.

Color coded accessories/speeds



Match the color of the speed with the color of the accessory for optimized results.

Accessory storage included



The accessory storage box keeps all your Philips food processor accessories easily at hand. It also helps you to keep all the sharp stainless steel accessories out of harm's way!

Dishwasher safe accessories



All Philips Food Processor accessories included in your box are dishwasher safe.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Accessories

Accessory storage box
Blender Jar
Emulsifying disc
French fry disc
Granulating disc
Grinder mill
Kneading tool
Reversible disc: slicing/shredding(coarse/fine)
Stainless steel S-blade

Design specifications

Color(s): Black

General specifications

Speeds: 2+ pulse
Cord length: 1 m
Grinder mill capacity: 250 ml
Blender jar size: 1.75L
Blender jar working capacity: 1.0L
Bowl capacity: 2 L
Bowl max working capacity: 1.5L (dry/liquid)
Bowl max working capacity.: 500g (Flour)
RPM-Blender&Grinder Mill(max): Up to 21000 rpm
RPM-Blender&Grinder Mill(min): Up to 16500 rpm

RPM-Bowl(max): Up to 1900 rpm
RPM-Bowl(min): Up to 1500 rpm
Product size (LxWxH): 210x210x368 mm

Technical specifications

Power: 750 W
Voltage: 220-240 V
Frequency: 50-60 Hz
Safety: Lid & bowl detection, mechanical 1.5 sec brake

