PHILIPS



Super-automatic espresso machine

Xelsis

Integrated milk jug & frother

Stainless steel



HD8944/47



Multi-beverage, multi-user

with full automated dual cleaning milk carafe

With the Xelsis each and every family member can enjoy his or her favorite coffee specialty. Thanks to the unique multi-user function up to 6 personal user profiles can be created and for each profile up to 9 beverages can be personalized.

Authentic Italian coffee perfection

- · Perfect milk froth thanks to the integrated milk carafe
- · Milk specialties without the wait thanks to a double boiler
- · Coffee without burnt taste thanks to 100% ceramic grinders

Set the beverages to suit your taste

- · Personalize your coffee in 6 user profiles
- Play with the coffee's richness with our adjustable grinders
- · Boost coffee crema and body

Ease of cleaning and maintaining

- ${}^{\textstyle \cdot}{}$ Always a clean machine thanks to auto-clean and descaling
- · Hygienic milk frothing thanks to automated dual cleaning
- Easy cleaning thanks to removable brewing group
- · Cutting-edge design with stainless steel finish

Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

8 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 8 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

6 user profiles



This Saeco espresso machine comes with 6 customizable profiles that memorize your personal preference for different coffee drinks. This makes it very easy to get a perfect tailormade cup of coffee although you are not the only one using the machine.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygene.

Automatic dual cleaning carafe



This Saeco espresso machine comes with a fully automated dual clean function for its milk carafe. The dual cleaning uses two independent steam cycles to swiftly rinse your

milk carafe after each coffee drink you prepare, for a fresh milk drink everytime. Hygienic milk frothing was never this easy.

Auto cleaning and descaling



Saeco designed this espresso machine to automatically clean its coffee circuit with water upon starting up or switching off of the machine, this delivers a great, fresh taste with each cup of coffee. Regular descaling prolongs your espresso machine's life. This machine will not only prompt when descaling is needed, the automated descaling process will start on your machine and guides you with clear on-screen messages when you have to intervene.

Descaling has never been so easy!

Professional double boiler



With 2 separate heating systems to cater for both the optimal coffee or milk frothing temperatures, this Saeco fully automatic espresso machine guarantees professional performance and speed everytime. You are able to prepare as many latte macchiatos and cappuccinos as you wish, one after the other and each just as good as the previous without waiting.

Specifications

Perfect Espresso

Espresso technology: Saeco adapting system, Aroma-system: pre-brewing, SBS: creme adaptor, Cup warmer

Service

1-year guarantee

Technical specifications

Supported coffee types: Ground coffee, Whole coffee beans

Water pressure in pump: 15 bar (perfect espresso)

Removable brewing group

Country of origin: Designed in Italy, Made in

Italy

Cord length: 80 cm

Number of water boilers: 2 boilers (instant

steam)

Frequency: 60 Hz

Power: 1500 W Voltage: 120 V

Boiler material: Stainless steel (Inox)

Multi-Beverage

Milk Variations: Frothing degree adaptor, Integrated auto milk function, Milk quantity selector, Removable milk carafe

Easy to use

Cleaning and maintenance: Automatic coffee circuit rinse, Automatic milk circuit rinse, Descaling cycle

Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Cup holding surface, Frontal access to all function, Instant steam (2 boilers), Removable brewing group, Removable watertank

Weight and dimensions

Product weight: 16.1 kg Maximum cup height: 150 mm

Product dimensions (L \times D \times H): 280 \times 370 \times

420 mm

Coffee bean capacity: 350 gr Waste container capacity: 14 servings

Milk carafe capacity: 0.5 L Water tank capacity: 1.6 L

Design

Materials and finishing: Full-body stainless steel

Energy saving

Energy saving: Automatic stand-by

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-03-12 Version: 4.0.1

EAN: 00 07502 00203

www.philips.com

