

PHILIPS

Mite Cleaning Vacuum Cleaner

Removes dust and mites

Reduces Allergens

Soft surfaces

450 W

FC6232



Safely and efficiently removes dust and mites

For an allergy friendly home

Philips Mite Cleaner removes dust and mites easily and effectively from soft surfaces. Its three functions make the cleaning of soft surfaces effortless. It also reduces allergens, for an allergy friendly home. Equipped with an UV-Light.

Safely and effectively removes dust and mites

- Powerful vibrating pads to loosen up dirt
- 450 W motor for powerful removal of dust and mites
- Suitable for cleaning all soft surfaces in your home
- Three different cleaning modes to suit your needs
- EPA 12 filter ensures dust will not escape again

Safe UV light

- Includes Philips UV light
- Three safety sensors automatically shut off UV light

Compact and easy to use

- Warning signal to ensure that dust container is well placed
- Easy to operate dust container for quick disposal of dirt
- Small brush is included to keep your product clean
- 5 meter cord allows for easy reach

Highlights

Vibrating pads



Three padding feet vibrate at a high speed of 3600 rpm to vigorously loosen dust and dirt from inside soft surfaces.

Powerful Vacuuming Motor

The combination of a powerful 450 W motor and 8.2 cm suction vent will ensure the effective removal of dust and mites from soft surfaces, reducing the allergens in your home.

Suitable for all soft surfaces



Effectively and safely remove dust and mites from beds, sofas, plush toys, cushions and all other soft surfaces for an allergy friendly home.

Cleaning mode selection

Three different modes allow you to select particular settings for cleaning specific surfaces, to better suit your cleaning needs.

Philips UV Light

Includes Philips UV light.

Auto off for UV light

Three safety sensors detect if product is in contact with a surface or not. It will automatically shut off the UV light to ensure safe operation, always.

Dust container sensor

Warning signal to ensure that dust container is well placed.

Easy to empty dust container



An easy to operate dust container makes the disposal of dust both simple and hygienic.

Small Maintenance Brush



Small brush is included to keep your product clean.

Easy reach

5 meter cord allows for easy reach.

EPA Filter

The EPA 12 Filters captures 99.5% of fine dust particles while filtering the exhaust air. This keeps dust securely within the container, preventing secondary contamination.

Specifications

Performance

Input power (IEC): 450 W
Punch Speed: 3600 rpm

Usability

Cord length: 5 m
Dust full indicator

Design

Color: Shining gold

Filtration

Exhaust filter: EPA 12 filter
Motor filter: Microfilter

Nozzles and accessories

Accessories included: Brush

Weight and dimensions

Dimensions of product (LxWxH): 425 x 300 x 190 mm
Weight of product: 3 kg



British Allergy Foundation

Seal of Approval This products helps you to manage the symptoms of your allergy, sensitivity or intolerance.