



Saeco Minuto Super-automatic espresso machine

- Brews 7 coffee varieties
- Classic Milk Frother
- Black
- 5 step adjustable grinder



HD8761/03

Always your favorite coffee at just one touch

With the one-click removable brewing group

Only the Saeco Minuto super-automatic espresso machine delivers the real first bean to cup experience with maximum convenience, top-notch performance and large capacities in extra compact dimensions

Authentic Italian coffee perfection

- Delicious milk froth thanks to the classic milk frother
- Coffee without waiting thanks to the quick heat boiler
- Coffee without burnt taste thanks to 100% ceramic grinders

Set the beverages to suit your taste

- Save your favorite coffee length and strength
- Play with the coffee's richness with our adjustable grinders
- Avoid heat loss and fit every cup with our adjustable spout

Ease of cleaning and maintaining

- Easy cleaning thanks to removable brewing group
- Dishwasher-safe drip tray and servings container
- Fully automatic rinsing and de-scaling



PHILIPS

Saeco, a Philips brand



Highlights

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a

"Pannarello". It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!

Saves coffee length & strength



You will always get a perfect cup of espresso brewed according to your personal preference, thanks to our memo function which allows you to adjust the coffee length and strength to suit your taste. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

Dishwasher-safe drip tray-part

You can comfortably put the drip tray and servings container in your dishwashe, giving them a perfect time-saving clean.

5 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

Fully automatic rinsing

Easy maintenance, long-lasting performance and always the best result in the cup are ensured thanks to our fully automated rinsing and de-scaling program.

Specifications

Technical specifications

- Number of water boilers: 1 boiler
- Water pressure in pump: 15 bar (perfect espresso)
- Supported coffee types: Ground coffee, Whole coffee beans
- Country of origin: Designed in Italy, Made in Europe
- Removable brewing group
- Power: 1850 W
- Voltage: 240 V
- Frequency: 50 Hz
- Cord length: 80 cm

Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

Finishing

- Material panarello: Plastic

Service

- 2-year worldwide guarantee

Easy to use

- Cleaning and maintenance: Descaling cycle
- Usage: Adjustable coffee dispenser, Rapid steam, Removable brewing group, Normal / long espresso option

Weight and dimensions

- Product weight: 7.5 kg
- Product dimensions (L x D x H): 215 x 429 x 330 mm
- Coffee bean capacity: 250 gr
- Waste container capacity: 15 servings
- Water tank capacity: 1.8 L
- Maximum cup height: 152 mm

Features

- Simultaneous brewing
- Brita Filter compatible: Optionable

Design

- Colour: Mat Black
- Materials and finishing: Plastic