Philips PerfectCare Viva Refurbished Steam generator iron

Refurbished product Max 6 bar pump pressure Up to 340 g steam boost 2-I water tank capacity

GC7057



## Iron faster with 2 x more steam \*

### no temperature setting required

Philips steam generator iron delivers a faster and easier ironing experience. Iron your garments with no temperature adjustment needed thanks to the revolutionary OptimalTEMP technology.

#### No temperature setting needed; no burning, guaranteed

- Go from ironing jeans to silk; no need to change temperature setting
- Safe to leave the hot soleplate on the ironing board

#### Fast ironing with continuous powerful steam

- · Powerful steam for ultimate crease removal
- Integrated easy-clean system for long-lasting performance
- · Philips' best gliding with increased scratch resistance
- Save energy with ECO mode

#### **Compact technology**

- Lightweight and compact size for easy storage
- Large water tank for longer continuous use
- Safe and secure carry lock
- Automatic switch-off for safety and energy saving

# PHILIPS

GC7057/20R1

## Highlights

#### **Ultra-powerful steam**



An ultra-fast ironing experience can be yours with revolutionary technology. The powerful and continuous steam tackles even tough creases, and thicker fabrics are smoothed out with ease and speed. Plus there's an extra steam boost if needed, perfect for vertical steaming or stubborn creases.

#### **OptimalTEMP** technology



With OptimalTEMP technology you'll no longer have to waste time changing temperature settings, waiting for the temperature to adjust or pre-sorting clothes. Iron all fabrics, from jeans to silk, with no burning guaranteed thanks to the perfect combination of temperature and continuous powerful steam. Safe rest



Innovative OptimalTEMP technology guarantees no burning on any ironable fabric. As well as the reassurance this provides whilst ironing, it also means you can leave the hot iron soleplate directly on your cotton ironing board without causing any damage. This helps to reduce any discomfort to your wrists, as you won't need to lift the iron to and from its base as often.

#### 2-I water tank



The water tank has an extra-large 2-I capacity, so you get the convenience of up to 2 hours of continuous use with no need to top up the tank. It's also transparent, so you can get a 360° view of the tank to easily see how much water you have left to continue creating steam efficiently. When you do need to refill, your steam generator iron has a large filling hole that allows you to easily fill the water tank under the tap, or alternatively with a jug or bottle at any time during ironing

Smart Calc clean



Regular descaling protects your iron and maintains steam performance. The Smart Calc-Clean system is an integrated descaling and cleaning function to extend the lifespan of your steam generator iron. The iron will remind you with both light and sound that cleaning and descaling is needed. Simply place your iron onto the Smart Calc-Clean container and start the process. It takes approx. 2 minutes for the dirty water and scale to be collected; your steam generator will beep once it's finished and ready to use again.

#### Lightweight and compact size



Thanks to revolutionary ProVelocity technology, we've been able to make a steam generator more compact than ever before. The smaller size fits perfectly on your ironing board for convenience, and carrying it around is made far easier. Plus your steam generator iron will take up much less storage space.

## Specifications

#### Technology

- · For all ironable fabrics
- No burns
- No temperature settings needed
- OptimalTEMP technology
- ProVelocity steam engine
- Smart Control Processor

#### Fast crease removal

- Continuous steam: up to 120 g/min
- Power: 2400 W
- Pressure: Max 6 bar pump
- Ready to use: 2 min
- Steam boost: up to 340 g
- Steam-on-demand
- · Variable steam levels
- Vertical steam
- Voltage: 220 240 V

#### Easy to use

- Safe on all ironable fabrics: Even delicates like silk
- Soleplate gliding performance: 5 stars
- Soleplate name: SteamGlide Plus
- Cord freedom (swivel): 360 degree cord freedom
- Hose length: 1.6 m
- Power cord length: 1.8 m
- Ready to use: Light indicator, Sound indicator

- · Refill anytime during use
- Safety auto off
- Soleplate scratch resistance: 4 stars
- Tap water suitable
- Heat-up time: 2 min
- Extra-large filling hole

#### Scale management

- Descaling and cleaning: Smart Calc Clean
- Descaling reminder: Light, Sound, Yes, no cartridges needed, no extra

#### **Accessories included**

• Calc clean container

#### Storage

- Carry lock: For transportation and safety
- Cord storage: Velcro fix
- Hose storage: Hose storage compartment

#### Size and weight

- Packaging dimensions (W x H x D): 42.7 x 23.8 x 33.5 cm
- Product dimensions (W x H x D): 32.2 x 19.4 x 23.6 cm
- Weight of iron: 1.2 kg
- Weight of iron + base: 4.1 kg



Issue date 2020-10-21

Version: 1.0.1

All Rights reserved. Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

© 2020 Koninklijke Philips N.V.

www.philips.com

12 NC: 0000 041 03007 EAN: 87 10895 69243 4

\* Compared to Philips steam iron EasySpeed

