



**Saeco Intuita
Super-automatic
espresso machine**

- Brews 3 coffee varieties
- Classic Milk Frother
- Black
- 5 step adjustable grinder



HD8750/47

Espresso from fresh beans

Select your aroma with this espresso machine

Saeco Intuita espresso machine offers you the possibility to taste freshly ground espresso at the touch of a button, aroma selection, easy to use, easy to customize and easy to clean

Advanced technology designed for coffee perfection

- Fine-tune the coffee's richness with 5 grinder settings
- Extract maximum flavor with the 100% ceramic grinders
- Velvety milk foam with the Classic Milk Frother

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time
- Auto-cleaning cycle removes any hassle

PHILIPS

Saeco, a Philips brand

 **Saeco**



Highlights

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has five adjustable settings - from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

100% Ceramic grinders



The robust 100% ceramic grinders guarantee a moment of pure coffee indulgence for years to come. The ceramic material creates the ideal grind, which allows the water to flow through steadily, extracting the purest essence of the beans. And unlike other 'regular' grinders, the ceramic material prevents the coffee from overheating and tasting burnt.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean - just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Auto-cleaning



The automatic cleaning cycle makes it easy to look after, and it increases the machine's longevity - giving you more time to enjoy your coffee instead of cleaning up.

Classic Milk Frother



The Classic Milk Frother is for those who love to assume the role of master craftsman, and it's just easy. Within seconds you can create a rich, silky layer of foam - the crowning glory of your coffee.

Specifications

Weight and dimensions

- Dimensions of product (WxDxH): 256 x 440 x 340 mm
- Weight of product: 8.0 kg

General specifications

- Special functions: Ceramic grinder, Hot water option, Manual milk frother Pannarello, Pre-brewing, Steam option
- Coffee drinks: Espresso, Cappuccino, hot water, Café Crème, frothed milk, Espresso Macchiato, Latte Macchiato
- Suitable for: Whole coffee beans
- Cups at the same time: 2
- Ease of cleaning & maintenance: Automatic descaling cycle, Automatic rinse cycle, Optional Brita water filter, Dishwasher-safe parts, Removable brewing group
- Ease of use and comfort: Adjustable spout, Removable drip-tray, Removable water tank
- Type of boiler: Quick heat boiler
- Customizing per drink: Adjustable cup volume

Finishing

- Material drip tray: Stainless steel
- Material panarello: Plastic
- Material water tank: Plastic
- Material of main body: Plastic
- Material boiler: Stainless steel (Inox)

Service

- 1-year guarantee

Design

- Color: Black

Country of origin

- Made in: Europe

Technical specifications

- Cord length: 0.8 m
- Frequency: 60 Hz
- Voltage: 120 V
- Water boilers: 1
- Max. cup height: 130 mm
- Capacity bean container: 300 gr
- Pump pressure: 15 bar
- Capacity waste container: 15 servings
- Capacity water tank: 1.5 L

Sustainability

- Power consumption brewing: 1850 W