

PHILIPS

Food processor

Pure Essentials
Collection

1000 W

Compact 2 in 1 setup

3.4 L bowl



HR7774/90



Effortless excellence

Bigger tube. Bigger bowl. More power. Less effort

This state-of-the-art food processor has some of the most advanced technologies. Its versatility is ensured by 7 accessories which easily perform 30+ functions.

Powerful precision

- 1000 W motor
- Ice and pulse functions for chopping and crushing
- Adjustable blade for slices between 1-7 mm

Effortlessly easy

- 7 accessories to easily perform 30+ functions
- XL feeding tube takes whole fruits or vegetables
- Up to 7 portions in 1 go with the XL bowl
- One touch (dis)assembly

Stylishly compact

- Compact 2-in-1 setup saves countertop space

Reliably durable

- Dishwasher safe accessories

Highlights

30+ functions



The – dishwasher safe – accessories are a kneading tool for mixing batter and for heavy kneading. A stainless steel chopping knife to prepare meat and vegetables. Two metal disks to handle medium and fine shredding and grating. Break resistant blender of 1.5l for blending, crushing up to stirring different ingredients. A citrus press for pressing citrus fruits. And a balloon beater for whipping and whisking and handling light batter.

Adjustable slicing blade

With the adjustable slicing blade, you can make slices as thin as 1 mm and up to 7 mm thick.

1000 W motor

With the powerful 1000 W motor of this Philips food processor you can adjust speed precisely to get desired results.

XL feeding tube



The XL feeding tube takes whole fruits and vegetables so you don't need to pre-cut them anymore.

XL 3.4 L bowl



The XL bowl allows for maximum volumes to be processed in one go: capacity for 2 l soup, 1.7 kg dough, 7 eggwhites.

Compact 2-in-1 setup



Compact setup fits blender or bowl to save countertop space

Specifications

Technical specifications

Voltage: 220-240 V
Frequency: 50-60 Hz
Bowl capacity dry: 3.4 L
Bowl capacity liquid: 2 L
Bowl working capacity dough: 1700 g
Bowl working capacity flour: 1000 g
Blender jar capacity: 1.5 L
Safety: Lid & bowl detection, mechanical 1.5 sec brake
Speeds: Variospeed
Cord length: 120 cm

Accessories

Number of inserts/discs: 2
Reversible shredding disk: For medium and fine shredding
Adjustable slicing disk: For 1-7 mm slices of fruit & vegetables
Citrus press: For pressing of citrus fruits
Kneading tool: For kneading, heavy kneading, mixing dough, batter
Stainless steel chopping knife: chopping, Beating, creaming, crumbling, cutting, folding in, mashing, mincing
Balloon beater: Double beater for whipping, whisking, mixing and emulsifying
Break resistant blender: blending, crushing, foaming, grinding, pureeing, homogenizing, liquidizing, milling, shaking, stirring
Recipe book

Design specifications

Housing: ABS
Knife holder, balloon beater: POM
Disks, chopping blade: Stainless steel
Speed knob: Brushed aluminium
Kneading tool, citrus press: PP
Function buttons: Pulse, Ice
Pusher, inner pusher: ABS, SAN
Bowl including lid and blender: SAN
Color(s): Black

General specifications

Integrated cord storage
Non-slip feet

Country of origin

China

