

# PHILIPS

Steam generator  
iron

PerfectCare  
Performer

Max 6 bar pump pressure

Up to 360 g steam boost

1.8 l water tank capacity

Detachable water tank



GC8715/20



## Ultra-fast ironing

with powerful continuous steam

The Philips PerfectCare Performer steam generator iron ensures a truly simple, powerful and burn-free ironing experience. The powerful continuous steam penetrates deeply and continuously into the fibre to remove creases easily.

### No temperature setting needed; no burning, guaranteed

- Go from ironing jeans to silk; no need to change temperature setting
- Safe to leave the hot soleplate on the ironing board
- Tested and approved by independent textile experts

### Fast ironing with continuous powerful steam

- Powerful steam for ultimate crease removal
- Integrated easy-clean system for long-lasting performance
- Philips' best gliding with increased scratch resistance
- Save energy with ECO mode

### Extra convenience

- Lightweight steam generator for easier handling
- Large detachable water tank for easy refilling
- Safe and secure carry lock



[asimpleswitch.com](http://asimpleswitch.com)

# Highlights

## 1.8 l detachable water tank



The detachable water tank allows you to easily refill anytime without stopping the appliance. It has a large filling hole so you can simply fill the water tank under the tap. It has a 1.8 l capacity, so you get the convenience of up to 2 hours of continuous use, with no need to top up the tank.

## Lightweight steam generator



Thanks to revolutionary ProVelocity technology, we've been able to make a powerful steam generator iron that is much lighter than traditional models. This means it's more stable when positioned on your ironing board and carrying it around is much easier.

## OptimalTEMP technology



With OptimalTEMP technology you'll no longer have to waste time changing temperature settings, waiting for the temperature to adjust or pre-sorting clothes. Iron all fabrics, from jeans to silk, with no burning guaranteed thanks to the perfect combination of temperature and continuous powerful steam.

## Safe carry lock



Your steam generator iron includes a safe carry lock, which securely fastens your iron to its base without the risk of it slipping or someone touching the hot soleplate. It ensures safe and easy transportation around the house, to and from storage.

## Safe rest



Innovative OptimalTEMP technology guarantees no burning on any ironable fabric. As well as the reassurance this provides whilst ironing, it also means you can leave the hot iron soleplate directly on your cotton ironing board without causing any damage. This helps to reduce any discomfort to your wrists, as you won't need to lift the iron to and from its base as often.

## Smart Calc clean



Regular descaling protects your iron and maintains steam performance. The Smart Calc-Clean system is an integrated descaling and cleaning function to extend the lifespan of your steam generator iron. The iron will remind you with both light and sound that cleaning and descaling is needed. Simply place your iron

onto the Smart Calc-Clean container and start the process. It takes approx. 2 minutes for the dirty water and scale to be collected; your steam generator will beep once it's finished and ready to use again.

## Tested and approved



This iron is tested and approved by independent textile expert institutes, such as DWI, IWTO and Woolmark, for its excellent ironing performance. The Woolmark Apparel Care programme helps consumers to identify quality laundry products that are approved by The Woolmark Company for use on wool products. Philips, with its exclusive OptimalTEMP technology, is so far the only ironing brand to be certified with the Gold standard from Woolmark. You can be confident that our Woolmark-approved apparel care products are ideal for any wool garments.



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

# Specifications

## Technology

For all ironable fabrics  
No burn  
OptimalTEMP Technology  
ProVelocity steam engine  
Smart Control Processor

## Fast crease removal

Continuous steam: Up to 120 g/min  
Power: 2600 W  
Pressure: Max 6 bar pump  
Ready to use: 2 min  
Steam boost: Up to 360 g  
Steam-on-demand  
Variable steam levels  
Vertical steam

## Easy to use

Safe on all ironable fabrics: Even delicates like silk  
Soleplate gliding performance: 5 stars

Soleplate name: SteamGlide Plus  
Detachable water tank  
Hose length: 1.6 m  
Power cord length: 1.8 m  
Precision steam tip  
Ready to use: Light indicator, Sound indicator  
Refill anytime during use  
Soleplate scratch resistance: 4 stars

## Scale management

Descaling and cleaning: Smart Calc Clean  
Descaling reminder: Light, Sound, Yes

## Storage

Carry lock: For transportation and safety  
Cord storage: Velcro fix, Yes  
Hose storage: Hose storage compartment

## Size and weight

Packaging dimensions (W x H x D): 24.6 x 33.5 x 44.9 cm  
Product dimensions (W x H x D): 22 x 24 x 37 cm  
Weight of iron: 1.22 kg  
Weight of iron + base: 3.2 kg

## Guarantee

2 year worldwide guarantee

## Green efficiency

Energy saving mode  
Product packaging: 100% recyclable  
User manual: 100% recycled paper

