



**Saeco Xsmall
Super-automatic
espresso machine**

- Brews 2 coffee varieties
- Classic Milk Frother
- Black
- 5 step adjustable grinder



HD8743/31

Taste the aroma of your favourite coffee beans
one touch bean to cup espresso

Everything you need to embark on a never-ending aroma discovery

Advanced technology designed for coffee perfection

- Fine-tune the coffee's richness with 5 grinder settings
- 20,000 cups of finest coffee with durable ceramic grinders


High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time
- Auto-cleaning cycle removes any hassle

 **Saeco**

PHILIPS

Saeco, a Philips brand



Highlights

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has five adjustable settings - from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

100% Ceramic grinders



Our grinders are made of high-tech ceramic: exceptionally hard and precise. Fresh beans are gently ground, without risk of overheating: extracting all the best flavors and aroma, delivering a superior coffee taste for at least 20,000 cups.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Auto-cleaning



The automatic cleaning cycle makes it easy to look after, and it increases the machine's longevity – giving you more time to enjoy your coffee instead of cleaning up.

Specifications

Sustainability

- Power consumption brewing: 1400 W

General specifications

- Cups at the same time: 2
- Suitable for: Whole coffee beans, ground coffee powder
- Type of carafe: Basic carafe
- Special functions: Ceramic grinder, Manual milk frother Pannarello, Pre-brewing
- Ease of use and comfort: Removable water tank
- Ease of cleaning & maintenance: Removable brewing group, Automatic rinse cycle, AquaClean filter compatible
- Coffee drinks: Espresso, hot water, Café Crème

Finishing

- Material boiler: Stainless steel (Inox)
- Material of main body: Plastic
- Material water tank: Plastic

Service

- 2-year guarantee

Technical specifications

- Pump pressure: 15 bar
- Capacity bean container: 180 gr
- Capacity waste container: 8 servings
- Max. cup height: 95 mm
- Water boilers: 1
- Cord length: 0.8 m
- Capacity water tank: 1 L
- Frequency: 50 Hz
- Voltage: 230 V

Weight and dimensions

- Weight of product: 7.2 kg
- Dimensions of product (WxDxH): 295 x 420 x 325 mm

Design

- Color: Black

Country of origin

- Made in: Europe