

Philips
Pressurised steam
generator

GC7230



Faster ironing - from start to finish

Pressurised steam power with fast-fill water tank

Created to speed up ironing from start to finish, GC7230 is ready to use in 2 minutes.

Pressurised steam power speeds up ironing by penetrating deeper into fabric and the extra-large water-filling funnel allows fast & easy refills anytime.

Full control

- Variable steam settings to suit every garment

Smooth gliding

- SteamGlide soleplate for powerful steam and superb gliding

Reaches into tricky areas

- Steam tip lets you iron right into hard-to-reach areas

Fast and powerful ironing

- Up to 4 bars of steam pressure for fast ironing
- Ready to use in 2 minutes
- Continuous steam up to 80 g/min for fast crease removal
- Water-filling funnel allows fast and easy refills anytime

Comfortable ironing

- Steam trigger lock gives steam without needing to press down

PHILIPS
sense and simplicity

Specifications

Comfortable ironing

- Additional comfort: Steam trigger lock
- Anti-scale management: Easy Rinse
- Cord length: 2 m
- Hose length: 1.7 m
- Safe in use: Overheat safety stop
- Suitable for tap water

Crease removal

- Soleplate: Optimal vent pattern
- Vertical Steam: Continuous vertical steam

Easy to use

- Control: Steam ready light, Temperature ready light,

- Water tank empty light
- Easy to set up and store: Easy cord and hose storage
- Reaching tricky areas: Button groove

Technical specifications

- Boiler wattage: 1400
- Frequency: 50-60
- Iron wattage: 800
- Voltage: 220 - 240

Weight and dimensions

- Product dimensions: 429 x 400 x 206
- Product weight: 6,1

Highlights

Steam tip

The unique steam tip combines a particularly pointed front of the soleplate with special steam slots in the tip to reach right into the smallest and most difficult areas for the best ironing results.

Up to 4 bars steam pressure



Double your ironing speed with pressurized steam. Pressurized steam penetrates deep into fabrics, making your ironing fast and easy, even on difficult fabrics.

Quick start-up

When switched ON, the ironing system is ready for steam ironing in just 2 minutes.

Continuous steam up to 80 g/m

Continuous steam up to 80 g/min helps to efficiently remove all creases.

Extra-large water-filling funnel

Filling your iron's water tank has never been faster or easier. Simply open the easy-access lid and pour in the water. The large, funnel-like opening ensures quick, convenient filling without the risk of spillage. And water can be added anytime - before, during or after an ironing session - without having to wait for the iron to cool down.

Steam trigger lock

The steam trigger lock allows a user the possibility to have continuous steaming of the iron without having to press the trigger continuously.

SteamGlide Soleplate



This specially designed soleplate combines superior ceramic coating for superior gliding on all fabrics and carefully designed vents for powerful crease removal.



Issue date 2013-03-01

Version: 5.0.1

12 NC: 0000 000 00000

© 2013 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com