

# PHILIPS

Steam generator  
iron

SpeedCare

Max 4 bar pump pressure

1.2 L fixed watertank



GC6602



## Ironing faster with 2 x more steam\*\*

Philips SpeedCare steam generator delivers more steam than a steam iron, it helps you speed up ironing. Enjoy more quality time of the reduced ironing time with your loved family by using Philips SpeedCare steam generator iron.

### **Fast and powerful ironing**

- Max 4 bar pump pressure
- Ready to use in 2 minutes with unlimited refill
- Triple precision tip for optimal control and visibility
- Non-stick soleplate coating
- Smart Calc clean system with sound&light Calc Clean reminder
- 1.2 L water tank and refill anytime during ironing
- Compact size and light weight for easy storage

# Highlights

## Steam ready in 2 minutes

Steam is ready to use in 2min and can be refilled at anytime during ironing.

## 1.2 L water tank

SpeedCare steam generator has 1.2 L water tank capacity to allow your iron more than 1 hour, it helps you reduce the frequency of refilling everytime for the big laundry loads. The technology will also allow you refill the water tank during ironing without cooling down the appliance for 2 hours waiting to reill.

## Triple precision tip

The tip of this Philips iron is precise in 3 ways: it has a pointed tip, button groove and a sleek design of the nose. Triple Precision tip enables you to reach even into the most tricky areas, e.g. around the buttons or between the pleats.

## Non-stick soleplate

The soleplate of your Philips iron is coated with a special non-stick layer for good gliding performance on all fabrics.

## Max 4 bar pump pressure

The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing faster and better. Steam power can be regulated to fit your needs.

## Compact size and light weight

Thanks to the revolutionnary ProVelocity technology, we made your steam generator iron more compact than ever before. The compact steam generator fits easily on your ironing board making your ironing more convenient. In addition, your steam generator takes much less storage space.

## Smart Calc Clean system

Smart Calc Clean system is an intergrated descaling and cleaning fuction to protect your steam generator iron. After each about 10 hour ironing, you will be reminded by the soud and light of your steam genreator iron to perform calc clean process. The Calc Clean Container will provide you the convenience during the Calc Clean process, by just resting your iron on the container without holding your iron to stress your waist. After cleaning process, all the dirty water is collected in the container, your steam generator iron is ready to use again.

# Specifications

## Calc management

Suitable for tap water

Calc clean solution: Smart Calc Clean

Calc clean reminder

Filtered water recommended

## Easy to use

Water tank capacity: 1200 ml

Filling and emptying water: Extra large filling hole

Refill any time

Heat up time: 2 min

Hose storage: Hose storage compartment

Cord freedom (swivel): 180 degree cord freedom

Hose length: 1.6 m

Power cord length: 1.8 m

## Fast & powerful crease removal

Vertical steaming

Pressure: Max 4 bar pump pressure

Power: 2400 W

Continuous steam output: 90 g/min

## Weight and dimensions

Packaging dimensions (WxHxL): 26.4 x 30.3 x 40.4 cm

Product dimensions (WxHxL): 19.8 x 21.7 x 34.6 cm

Weight of iron: 1.1 kg

Weight of iron + base: 2.6 kg

## Service

2-year worldwide guarantee

