

PHILIPS

2-in-1 Wet and Dry Cordless Vacuum Cleaner and Mop

PowerPro Aqua

Filters 90% bacteria and allergens

Mop and vacuum at the same time

Lightweight, 40min run time



FC6402/61



Vacuums and mops in one stroke

Always at hand to quickly clean daily messes

The new Philips PowerPro Aqua is a powerful cordless vacuum cleaner which does wet cleaning too. It combines vacuuming and mopping to quickly clean daily messes. Easy click-on/off mopping system to vacuum only, or vacuum and mop in one go!

Cleans everyday messes with vacuum and mop

- PowerCyclone technology for exceptional vacuum cleaning performance
- New mopping system with optimal wetness for all hard floors
- TriActive Turbo nozzle for powerful performance on carpets
- 3 layer filter technology captures micro particles

Always at hand and convenient for daily usage

- Cordless cleaning: freedom to clean everywhere
- Powerful 18 V Lithium Ion battery for long runtime
- Bagless: One-step empty dust bucket
- Instant click on/off mopping system for wet cleaning
- Manoeuvrable and lightweight for easy handling
- Suitable to use on all floors
- Washable foam filter for life-long performance



asimpleswitch.com

Highlights

PowerCyclone technology



The PowerCyclone technology delivers powerful vacuum cleaning performance. Air enters rapidly into the PowerCyclone and is accelerated further through the curved air pass to effectively separate dust from air.

Innovative mopping system



The unique mopping system controls the water release to maintain optimal wetness for all hard floors throughout cleaning.

TriActive Turbo nozzle



The TriActive Turbo nozzle delivers powerful performance on hard floors and carpets. The motorised brush and the optimised airflow pick up all dirt and fluff in one go.

3 layer filter



3 layer washable filter can capture >90% of allergens like pollen, pet hair and dust, for clean air.

Cordless cleaning



Without the cord, you are free to clean wherever you want on every type of floor.

Powerful Lithium Ion battery



Cordless cleaning with powerful 18 V Lithium Ion battery for 40 min runtime. With no more cable getting in your way, cleaning from room to room is hassle-free.

One-step empty dust bucket



The new bagless PowerPro Aqua vacuum cleaner allows you to dispose of dust from the dust bucket without having to touch it.

Click on/off mopping system



With the magnets on the water tank, the mopping system can easily be clicked onto and off the nozzle

Light and manoeuvrable

Good manoeuvrability and light weight are assured with the new PowerPro Aqua vacuum cleaner for easy handling.

Suitable to use on all floors



Vacuum all hard floors and carpets. Click on the water tank to mop all types of hard floors.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas — Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Performance

Battery type: Li-Ion

Battery voltage: 18 V

Runtime: 40 minute(s)

Sound power level: 83 dB

Surface coverage per tank: 50 m²

Charging time: 5 hour(s)

Usability

Clean water tank capacity (max): 0.2 l

Design

Design features: On-off

Colour: Grey

Filtration

Exhaust filter: Foam filter

Dust capacity: 0.6 l

Nozzles and accessories

Accessories included: 2 microfibre pads

Standard nozzle: TriActive Turbo Nozzle

Sustainability

User manual: 100% recycled paper

Packaging: > 90% recycled materials

Weight and dimensions

Dimensions of product (LxWxH): 200 x 250
(ground surface); 1150 (height) mm

Weight of product: 4.7 kg

