

PHILIPS

Saeco

Automatic espresso
machine

Xsmall

Class

White



HD8745



Taste the aroma of your favorite fresh beans

One touch bean-to-cup espresso

Xsmall the smallest member of the bean-to-cup family combines design and functionality. Preparing an excellent espresso is done with one push of a button - your favorite beans are freshly ground for intense aroma.

Grind your favorite coffee beans

- One touch bean-to-cup espresso
- Adjustable ceramic grinders
- Small and energy efficient

Easy to use

- Pannarello to froth milk as you like
- Ergonomic in day-by-day operations

Easy to clean and maintain

- Automatic coffee circuit cleaning
- Removable brewing group

Highlights

Bean-to-cup espresso



Your favorite beans are always freshly ground so their entire aroma is captured in every cup. This way Philips-Saeco bean Saeco bean-to-cup espresso machines deliver excellent and fresh coffee enjoyment day after day.

Adjustable ceramic grinders



Whole beans are freshly ground for every cup by ceramic grinders, always preserving their full aroma and never overheating the coffee.

Auto coffee circuit cleaning



This feature makes sure that each and every coffee is as fresh as possible: Before going into and when returning from stand-by mode, the machine automatically cleans its coffee circuit.

Pannarello



With the pannarello you can froth your milk exactly according to your preferences. Just dip the pannarello in the milk, while slowly stirring the milk with a rotary movement. Froth the milk as long as you want for more or less foamy mikfroth.

Removable brewing group



The brewing group is at the heart of every fully automatic coffee machine and it should always be kept clean. A task that doesn't get any more convenient than with a Saeco: remove, rinse and re-insert – finished.

Small and energy efficient



Small size and frontal access to all functionalities make sure that the Xsmall fits in every kitchen. And thanks to its efficiency (Class A according to Swiss regulation) and auto shutdown it's very kind to the environment.

Ergonomic day-by-day



Philips-Saeco is a synonym for convenience: refilling beans or water, emptying the coffee-dump box or the drip tray, all compartments are directly accessible.

Specifications

Perfect Espresso

Espresso technology: Aroma-system: pre-brewing

Easy to use

Cleaning and maintenance: Automatic coffee circuit rinse, Descaling cycle

Usage: Removable brewing group, Removable watertank

Technical data

Boiler: Stainless steel

Frequency: 50 Hz

Power: 1400 W

Voltage: 230 V

Pump Pressure: 15 bar

Weight and dimensions

Dimensions: 295x325x420 mm

Coffee bean capacity: 180 gr

Dump box capacity: 8 servings

Water tank capacity: 1 l

