



Philips  
Handheld vacuum cleaner

3.6 V



FC6050

## Easy cleaning anywhere

### Precision nose piece

The specially designed Philips FC6050 (3.6 V) cleans anywhere easily, thanks to its extended nose piece. The FC6050 has 3 powerful rechargeable batteries that give you the freedom of efficient cordless cleaning wherever you want.

#### **Easily cleans in corners and along curves**

- Extended nose piece

#### **Always at hand**

- Slim charging base for wall and table

#### **Cordless cleaning power wherever you want**

- Powerful rechargeable batteries

#### **Lasting suction power**

- 2-stage filter system prevents early clogging

#### **Easily cleans delicate surfaces and narrow spaces**

- Brush tool and crevice tool

**PHILIPS**  
sense and simplicity

## Highlights

### Extended nose piece



The Philips Mini Vac FC6050 series has a long, narrow nose especially designed for precision cleaning. The extended nose piece makes it easy to clean in corners and along curves.

### Powerful rechargeable batteries



The Philips Mini Vac's rechargeable battery gives you the freedom of cordless cleaning wherever you want.

### 2-stage filter system prevents early clogging



The Philips Mini Vac's 2-stage filtration system ensures that, once inside, dirt cannot escape. The first filter blocks most dirt, while the pleated, second filter traps the finer dust particles.

### Brush tool and crevice tool



The Philips Mini Vac comes with a number of accessories to tackle any job with ease. The soft brush attachment is gentle on delicate surfaces and the crevice tool lets you clean even those awkward, hard-to-reach places.

## Specifications

### Design

- Color: Spicy orange

### Filtration

- Dust capacity: 0.3 l
- Filter system: 2-stage

### Nozzles and accessories

- Other accessories: Charging base

### Performance

- Airflow (max): 500 l/min
- Battery voltage: 3.6 V
- Charging time: 16-18 hour(s)
- Noise level (Lc IEC): 77 dB
- Runtime: 9 minute(s)
- Suction power (max): 7 W
- Vacuum (max): 1.7 kPa

### Usability

- Special features: Charging indication

### Weight and dimensions

- Dimensions of A-box (LxWxH): 402 x 397 x 453 mm
- Appliances per A-box: 6
- Dimensions of packaging (LxWxH): 419 x 125 x 190 mm

