

**Bagless Cyclonic** 

Crevice, brush tool, squeegee

Wet and Dry

FC6142/01





## Powerful MiniVac for a better cleaning result Wet and Dry system and aerodynamic nozzle

Enjoy a better cleaning result with the powerful Philips MiniVac Wet & Dry 4.8 V vacuum cleaner. Clean both liquid spills and dry dirt in comfort with its wet-and-dry system. The aerodynamic nozzle design ensures superior dust pick-up.

## High power guaranteed

• Powerful 4.8 V NiMH batteries

## **Superior cleaning results**

· Aerodynamic nozzle design for a better dust pick-up

## **Optimal filtration**

• 2-stage bagless cyclonic airflow for optimal filtration

## Easy to use

- · Looped handle ensures optimum grip
- · One-step click-off nozzle for easy emptying

## Always at hand

· Slim charging base (for wall or table)

# Highlights

## Slim charging base (for wall or table)



You can store the Philips Mini Vac on the convenient charging base, mounted on a wall or placed on a table. This means the Mini Vac, with its powerful rechargeable battery, is always ready when you are.

#### 2-stage bagless cyclonic



The bagless cyclonic airflow keeps the dirt inside rotating to ensure optimal high suction power and lasting cleaning performance. Its 2-stage filtration system ensures that, once inside, the dirt cannot escape. The first filter blocks most dirt, while the second filter traps the finer dust particles.

## Aerodynamic nozzle design

The aerodynamic nozzle design of the Philips MiniVac is created to ensure optimum dust pick-up of even the finest dust particles. The ergonomic shape of the nozzle helps you to clean even the most hard-to-reach areas.

#### Comfortable grip



The Philips Mini Vac has a looped handle that ensures optimum grip. You can grab the Mini Vac in any way you like. The soft rubber coating feels gentle and gives the firm grip you need.

#### Powerful 4.8 V NiMH batteries



Powerful 4.8 V NiMH batteries

## One-step click-off nozzle

The Philips MiniVac vacuum cleaner is easy and quick to empty and hygienic to clean. The Philips MiniVac has a nozzle that easily clicks off in just one step, so you can empty the MiniVac without touching the dirt.

# Specifications

#### Design

Colour: Blue

Design features: Translucent dust chamber

#### **Filtration**

Dust capacity: 0.5 l

Filter system: Wet and dry system

## **Nozzles and accessories**

Accessories included: Charging base

#### **Performance**

Battery voltage: 4.8 V Charging time: 16-18 hour(s) Input power (max): 56 W Runtime: 9 minute(s) Suction power (max): 9 W Vacuum (max): 2.9 kPa Airflow (max): 530 l/s Sound power level: 76 dB

## Weight and dimensions

Dimensions of packaging (L x W x H): 508 x

335 x 490 mm

Weight of product: 1.4 kg

Dimensions of product (LxWxH): 460 x 160 x

160 mm

© 2019 Koninklijke Philips N.V. All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips N.V. or their respective owners.

Issue date 2019-11-13 Version: 13.10.1

12 NC: 0000 000 00000

www.philips.com

