

PHILIPS

Vacuum cleaner
with bag

Jewel

2000W

425W suction power

HEPA 12 filter

Anti-Allergy



FC9064/02



Beautiful results in a blink of an eye

TriActive nozzle with unique 3-in-1 action

The Jewel range is ideal for those who want beautiful results fast. It comes with the patented Tri-active nozzle that gives you three cleaning actions in one stroke.

Beautiful floors in a blink of an eye

- 2000 Watt motor generating max. 450 Watt suction power

Clean air in your home

- Super Clean Air HEPA 12 filter, 99.5% filtration

Easy cleaning, even around furniture

- TriActive nozzle with unique 3-in-1 action

Highlights

2000 Watt motor



Highly efficient 2000 Watt motor generates max. 450 Watt suction power for perfect cleaning results.

Super Clean Air HEPA 12 filter



This Super Clean Air HEPA 12 filter catches at least 99.5% of all harmful microscopic vermin that causes respiratory allergies.

TriActive nozzle



The TriActive nozzle cleans your floor in 3 ways in one go: 1) A larger opening at the tip of the nozzle easily sucks up big bits. 2) It has maximum cleaning efficiency due to optimized airflow through the nozzle. 3) The two side brushes sweep up the dust and dirt closely alongside furniture and walls.

Specifications

Design

Color: Deep red

Filtration

Dust bag type: s-bag

Exhaust filter: Super Clean Air HEPA 12 filter

Dust capacity: 3 l

Nozzles and accessories

Accessories included: Crevice tool, Small nozzle

Standard nozzle: TriActive nozzle

Performance

Airflow (max): 43 l/s

Input power (IEC): 1800 W

Input power (max): 2000 W

Noise level (Lc IEC): 76 dB

Suction power (max): 450 W

Vacuum (max): 32 kPa

Usability

Carrying handle: Front

Clean Comfort cassette

Tube coupling: Button

Dust bag full indicator

Power control: Electronic on appliance

Tube type: Metal lacquered 2-piece telescopic tube

Wheel type: Plastic

Action radius: 10 m

Cord length: 7 m

Weight and dimensions

Weight of product: 5.7 kg

