

# PHILIPS

Steam generator  
iron

PerfectCare Elite

Max 7.5 bar pressure

Up to 500 g steam boost

1.8 L water tank capacity

Detachable water tank



GC9614/20



## Most powerful steam for the fastest ironing\* with Ultra-light iron

PerfectCare Elite is the best and most efficient steam generator iron from Philips. With OptimalTEMP technology, you can now iron from jeans to silk with no temperature setting needed. Guaranteed no burns on all ironable garments.

### **No temperature setting needed, guaranteed no burn**

- Iron jeans to silk, no need to change temperature setting
- Safe to leave the hot soleplate on the ironing board

### **Fast ironing with continuous powerful steam**

- Powerful steam for ultimate crease removal
- Easy and efficient descaling system
- Philips best gliding and most scratch resistant soleplate
- Save energy with ECO mode

### **Ultimate ironing experience**

- Light weight and comfortable to handle
- Large detachable water tank for easy refilling
- Safe and secure carry lock
- Automatic switch off for safety and energy saving



[asimpleswitch.com](http://asimpleswitch.com)

# Highlights

## Ultra powerful steam



An ultra-fast ironing experience can be yours with revolutionary technology. The powerful and continuous steam tackles even rough creases, and thicker fabrics are smoothed out with ease and speed. Plus there's an extra steam boost if needed, perfect for vertical steaming or stubborn creases.

## OptimalTEMP technology



With OptimalTEMP technology you'll no longer have to waste time changing temperature settings, waiting for the temperature to adjust or pre-sorting clothes. Iron fabrics from jeans to silk, with guaranteed no burns thanks to the perfect combination of temperature and continuous powerful steam.

## Safe rest



Innovative OptimalTEMP technology guarantees no burn on all ironable fabrics. As well as the reassurance this provides whilst ironing, it also means you can leave the hot iron soleplate directly on your cotton ironing board without causing any damage. This helps to reduce any discomfort to your wrists, as you won't need to lift the iron to and from its base as often.

## Ultra-lightweight iron



Your steam generator's iron has the ideal weight: amazingly light weight and comfortable to handle. It glides easily over your garments, removes the toughest creases in no time, and reduces stress on your wrist. It makes also vertical steaming very easy and effective. You can now comfortably & effectively remove the creases of your delicate, like silk blouse, dresses, and jackets and even difficult to iron garments with pleats, decorations, buttons etc in a vertical way.

## 1.8 L detachable water tank



The detachable water tank allows you to easily refill anytime without stopping the appliance. It has a large filling hole so you can simply fill the water tank under the tap. It has a 1.8 L capacity, so you get the convenience of up to 2 hours of continuous use, with no need to top-up the tank.

## Easy De-Calc Plus



Regular descaling protects your iron and ensures you'll continue to get the very best steam performance. The exclusively designed and ideally positioned Easy De-Calc Plus function provides the ideal way to get rid of lime scale and extend the lifespan of your

steam generator iron. The iron will remind you with both light and sound when it's time to clean and descale. Then when your appliance is cold, simply remove the Easy De-Calc knob, collect the dirty water and scale into a cup and discard.

## T-ionicGlide soleplate



The T-ionic Glide is Philips' most premium soleplate, promising superior gliding for more effortless and fast ironing. It has a stainless steel base which is harder and more durable than aluminum, with an integrated titanium oxide layer for advanced scratch resistance. Plus the carefully designed shape and vents provide an even better steam distribution for faster crease removal.



[asimpleswitch.com](https://www.asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

# Specifications

## Technology

Cyclonic steam chamber  
For all ironable fabrics  
No burns  
No temperature settings needed  
OptimalTEMP technology  
Smart Control Processor

## Fast crease removal

Continuous steam: Up to 150 g/min  
Power: Max 2400 W  
Pressure: Max 7.5 bar  
Ready to use: 2 min  
Steam boost: Up to 500 g  
Steam-on-demand  
Variable steam levels  
Vertical steam  
Voltage: 220 - 240 V

## Easy to use

Safe on all ironable fabrics: Even delicates like silk  
Soleplate gliding performance: 5 stars

Soleplate name: T-ionicGlide  
Water tank capacity: 1800 ml  
Detachable water tank  
Hose length: 1.6 m  
Low water alert  
Power cord length: 1.65 m  
Precision steam tip  
Ready to use: Light indicator  
Refill any time during use  
Safety auto off  
Soleplate scratch resistance: 5 stars  
Tap water suitable  
Heat up time: 2 min  
Extra large filling hole

## Scale management

Descaling and cleaning: Easy De-calc Plus  
Descaling reminder: Light, Yes

## Storage

Carry lock: For transportation and safety  
Cord storage: Cord storage compartment, Velcro fix  
Hose storage: Hose storage compartment

## Size and weight

Packaging dimensions (WxHxL): 31 x 35 x 51 cm  
Product dimensions (WxHxL): 23.3 x 28.5 x 45.3 cm  
Weight of iron: 0.8 kg  
Weight of iron + base: 5.1 kg

## Guarantee

2 year worldwide guarantee

## Green efficiency

Energy saving mode  
Product packaging: 100% recycable  
User manual: 100% recycled paper

