

PHILIPS

Food processor

Daily Collection

650W

Compact 2 in 1 setup

2.1 L bowl

Accessories for + 25 functions



HR7628/00



Maximum variety of recipes, minimum effort

Create home made breads, cakes, drinks and more

This Philips Daily collection Food Processor has a compact design including a 2.1L bowl and 1.75 L blender and a variety of high performance accessories. Preparing delicious homemade food has never been so easy!

Powerful precision

- PowerChop technology for superior chopping performance

Maximum variety of recipes

- Emulsifying tool for cream and egg whites
- High performance stainless steel disc inserts
- Sharp and strong stainless steel S blade for chopping
- Up to 5 portions in one go

Easiest assembly, use and cleaning

- No mess from center of the bowl due to lack of inner shaft
- 40% larger feeding tube (compared to Philips HR7625)
- 650 Watt motor for powerful processing
- 2 speed settings and pulse for maximum control
- Dishwasher safe accessories

Reliably durable

- Break resistant jar



asimpleswitch.com

Highlights

2 speed settings and pulse



For best results, use the low speed setting (speed 1) to whip cream, beat eggs, create pastries and bread dough. The higher speed setting (speed 2) is well suited to chop onions and meats, blend soups and smoothies or shred, slice, grate or rasp vegetables.

PowerChop technology



PowerChop

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!

Powerful processing

650 W

This Philips Food Processor offers a powerful motor providing power and control to prepare all your favorite recipes.

Up to 5 portions in one go



The generous 2.1L bowl (1.5 L working capacity) enables you to blend up to 5 portions of soup in one go.

Dishwasher safe accessories



All accessory parts of your Philips food processor can be put on the top rack of your dishwasher for easy cleaning.

Break resistant jar



1.75L (1L working capacity) break resistant jar makes up to 5 glasses of smoothie.

Emulsifying tool



The perfect tool for whipping, whisking or emulsifying eggs or whipped cream. For best volume increase and fluffiness, use the low speed setting. Creating delicious desserts or mayonnaise has never been easier!

Stainless steel disc inserts



Simply select the right stainless steel disc insert to prepare your favorite ingredient and click it onto the disc holder. Performance has been tested extensively to provide the best slicing and shredding results.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Accessories

Kneading tool
Emulsifying disk
Disc insert: granulating
Disc insert: shredding(coarse)
Disc insert: slicing(coarse)
Stainless steel S-blade
Blender Jar

Design specifications

Housing: ABS
Speed knob: ABS
Pusher: SAN
Disc inserts, chopping knife: Stainless steel
Bowl including lid: SAN

Kneading tool: PP
Blender Jar: SAN
Blender Lid: PP
Knife holder: PP

General specifications

Speeds: 2 + pulse
Non-slip feet
Integrated cord storage
Blender jar size: 1.75L
Blender jar working capacity: 1.0L
Bowl capacity: 2.1 L
Bowl max working capacity: 1.5L (dry/liquid)
Bowl max working capacity: 500g (Flour)
Product size (LxWxH): 244x244x377 mm

RPM-Blender&Grinder Mill(max): Up to 21000 rpm
RPM-Blender&Grinder Mill(min): Up to 16500 rpm
RPM-Bowl(max): Up to 1900 rpm
RPM-Bowl(min): Up to 1500 rpm

Technical specifications

Power: 650 W
Voltage: 220-240 V
Frequency: 50/60 Hz
Safety: Lid & bowl detection, mechanical 1.5 sec brake

