

Philips SpeedCare
Refurbished Steam
generator iron

Refurbished product

Max 4.5 bar pump pressure
140 g steam boost
1.2-l fixed water tank

GC6612



Faster and easier ironing**

with twice as much steam** as a steam iron

The Philips SpeedCare steam generator delivers more steam than a steam iron, helping you to speed up your ironing. Enjoy more quality time with your family thanks to the reduced ironing time with the Philips SpeedCare steam generator iron.

Fast and powerful ironing

- Ready to use in 2 minutes with unlimited refill
- Lock your iron securely to the base station
- Continuous steam up to 100 g/min
- Ceramic soleplate for better gliding performance
- Triple precision tip for optimal control and visibility
- Compact size and light weight for easy storage
- Smart Calc cleaning system with a sound and light cleaning reminder
- 1.2-l water tank and refill at any time during ironing
- Max 4.5 bar pump pressure

PHILIPS

Highlights

Steam ready in 2 minutes



Steam is ready to use in 2 minutes and can be refilled at any time during ironing.

Ceramic soleplate



Ceramic soleplate is scratch-resistant, glides well and is easy to clean.

ironing board making your ironing more convenient. In addition, your steam generator takes much less storage space.

Smart Calc cleaning system



The Smart Calc cleaning system is an integrated descaling and cleaning function that protects your steam generator iron. After around 10 hours of ironing, your steam generator iron will remind you to perform the Calc cleaning process with a sound and light notification. The iron conveniently rests on the Calc container as it collects the dirty water, so you don't have to strain to hold the iron during the process. After all the water has been collected in the container, your steam generator iron is ready to use again.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer and reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

Triple precision tip



The tip of this Philips iron is precise in 3 ways: it has a pointed tip, button groove and a sleek nose design. The triple precision tip enables you to reach even the most tricky areas, e.g. around the buttons or between the pleats.

1.2-l water tank



The SpeedCare steam generator has a 1.2-l water tank capacity to allow you to iron for over an hour. It helps to reduce the number of refills required for large laundry loads. The technology will also allow you refill the water tank during ironing without the appliance cooling down for 2 hours while it is waiting to be refilled.

Continuous steam



The more steam, the faster the ironing. The unique technology used in the Philips steam generator iron produces powerful steam, making ironing quicker, easier and better.

Compact size and light weight



Thanks to the revolutionary ProVelocity technology, we made your steam generator iron more compact than ever before. The compact steam generator fits easily on your

Specifications

Fast and powerful crease removal

- Pressure: Max 4.5 bar pump pressure
- Continuous steam output: 100 g/min
- Steam boost: 140 g
- Soleplate: Ceramic
- Vertical steaming
- Steam output control
- Power: 2400 W

Easy to use

- Heat-up time: 2 min
- Refill any time
- Storage solution: Carry lock
- Water tank capacity: 1200 ml
- Filling and emptying water: Extra-large filling hole
- Power cord length: 1.8 m
- Cord storage: Cord clip
- Hose length: 1.6 m
- Hose storage: Hose storage compartment
- Ultra-light and comfortable
- Cord freedom (swivel): 180 degree cord freedom

Calc management

- Suitable for tap water
- Calc clean reminder
- Calc clean solution: Smart Calc Clean
- Filtered water recommended

Technical specifications

- Weight of iron: 1.1 kg
- Weight of iron + base: 2.6 kg
- Product dimensions: 19.8 x 21.7 x 34.6 cm
- Packaging dimensions: 26.4 x 30.3 x 40.4 cm
- Voltage: 220 - 240 V

Accessories

- Calc Clean container

Service

- 2-year worldwide guarantee



Issue date 2019-12-04

Version: 1.0.1

12 NC: 0000 041 02007
EAN: 87 10895 68384 5

© 2019 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* Compared to Philips steam iron EasySpeed