



Saeco Xsmall  
Super-automatic  
espresso machine

## Fits in every kitchen

Saeco's most compact automatic espresso machine

With this compact entry model, the enjoyment of an italian espresso is possible in every kitchen.



### Grind your favorite coffee beans

- Bean to cup system
- Play with the coffee's richness with our adjustable grinders

### Fits in every kitchen

- Compact full automatic espresso machine

### Easy to use


- Frontal access for easy filling and emptying
- Easy cleaning thanks to removable brewing group
- Double shot

RI9745/01

 **Saeco**

**PHILIPS**

Saeco, a Philips brand



# Specifications

## Perfect Espresso

- Espresso technology: Saeco adapting system, Aroma-system: pre-brewing

## Multi-Beverage

- Milk Variations: Pannarello: milk frothing

## Easy to use

- Cleaning and maintenance: Automatic coffee circuit rinse
- Usage: Removable brewing group, Removable watertank

## Technical data

- Boiler: Stainless steel
- Frequency: 50 Hz
- Power: 1300 W
- Voltage: 230 V
- Pump Pressure: 15 bar

## Weight and dimensions

- Coffee bean capacity: 180 gr
- Waste container capacity: 8 servings
- Water tank capacity: 1 L

# Highlights

## Bean to cup system



It means that whole coffee beans are freshly ground and directly processed for each and every beverage.

## Double shot

With the double shot it is easy to serve 2 espresso's at a time.

## 5 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

## Compact design

With this compact design, the full automatic espresso fits in every kitchen.

## Easy frontal access

All machine elements you need to reach during your day-by-day enjoyment (water, coffeebeans and coffee grounds container, drip tray, removable brewing group) are completely independent and reachable either from the front or from the top.

## Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.