

# PHILIPS

Food processor

Daily Collection

650W

2 speeds + pulse

2.1 L bowl

Accessories for + 15 functions

HR7627/01



## Maximum variety of recipes, minimum effort

Create home made breads, cakes, drinks and more

This Philips Daily collection Food Processor has a compact design including a 2.1L bowl and a variety of high performance accessories. Preparing delicious homemade food has never been so easy!

### Powerful precision

- PowerChop technology for superior chopping performance

### Maximum variety of recipes

- Emulsifying tool for cream and egg whites
- High performance stainless steel disc inserts
- Sharp and strong stainless steel S blade for chopping
- Up to 5 portions in one go

### Easiest assembly, use and cleaning

- 2 speed settings and pulse for maximum control
- 40% larger feeding tube (compared to Philips HR7625)
- 650 Watt motor for powerful processing
- Dishwasher safe accessories
- No mess from center of the bowl due to lack of inner shaft



asimpleswitch.com

# Highlights

## 2 speed settings and pulse



For best results, use the low speed setting (speed 1) to whip cream, beat eggs, create pastries and bread dough. The higher speed setting (speed 2) is well suited to chop onions and meats, blend soups and smoothies or shred, slice, grate or rasp vegetables.

## 40% larger feeding tube



The new Philips Daily collection Food Processor comes with a feeding tube which is 40% larger than the previous HR7625 model, saving pre-cutting time of fruits and vegetables

## Powerful processing

# 650 W

This Philips Food Processor offers a powerful motor providing power and control to prepare all your favorite recipes.

## Up to 5 portions in one go



The generous 2.1L bowl (1.5 L working capacity) enables you to blend up to 5 portions of soup in one go.

## Dishwasher safe accessories



All accessory parts of your Philips food processor can be put on the top rack of your dishwasher for easy cleaning.

## Emulsifying tool



The perfect tool for whipping, whisking or emulsifying eggs or whipped cream. For best volume increase and fluffiness, use the low speed setting. Creating delicious desserts or mayonnaise has never been easier!

## Stainless steel disc inserts



Simply select the right stainless steel disc insert to prepare your favorite ingredient and click it onto the disc holder. Performance has been tested extensively to provide the best slicing and shredding results.

## PowerChop technology



## PowerChop

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!



[asimpleswitch.com](http://asimpleswitch.com)

## Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

# Specifications

## General specifications

Integrated cord storage

Non-slip feet

Speeds: 2 + pulse

Product size (LxWxH): 244x244x377 mm

RPM-Bowl(max): Up to 1900 rpm

RPM-Bowl(min): Up to 1500 rpm

Bowl max working capacity: 1.5L (dry/liquid)

Bowl capacity: 2.1 L

Bowl max working capacity.: 500g (Flour)

## Accessories

Emulsifying disk

Kneading tool

Number of inserts/discs: 3

Stainless steel chopping knife: Beating, chopping, crumbling, cutting, folding in, mashing, mincing

Stainless steel S-blade

Disc insert: granulating

Disc insert: shredding(coarse)

Disc insert: slicing(fine)

## Design specifications

Bowl including lid: SAN

Housing: ABS

Kneading tool: PP

Pusher: SAN

Speed knob: ABS

Disc inserts, chopping knife: Stainless steel

Knife holder: PP

## Technical specifications

Frequency: 50/60 Hz

Power: 650 W

Safety: Lid & bowl detection, mechanical 1.5 sec brake

Voltage: 220-240 V

