

PHILIPS

Saeco

Manual Espresso
machine

Poemia

Classic Milk Frother

Focus



HD8423/01



Authentic Italian Espresso every day

With pressurized crema filter

The Saeco manual espresso machine offers enthusiasts of traditional preparation everything for a perfect daily espresso. The patented pressurized filter Crema guarantees a long lasting delicious crema, at every use.

Authentic Italian Espresso

- Pressurized Crema filter holder
- 15 bar pump
- Cup holder

Simplicity and speed of use

- Suitable for ground coffee and pads
- Delicious milk froth thanks to the classic milk frother
- Ergonomic in day by day operations

Every day use

- Long lasting premium materials
- Energy efficient



asimpleswitch.com

Highlights

Pressurized Crema filter



This special Crema filter guarantees a long-lasting, delicious Crema – whatever coffee blend you may choose.

Ground coffee and pads



For your convenience you can choose between ground coffee pads

15 bar pump



High pressure ensures that the ground coffee entire aroma is always fully extracted

Long lasting premium materials



Saeco Manual Espresso machine features high quality and durable housing material.

Cup holder



With this practical feature you can store your espresso cups and glasses right on the espresso machine – always within reach and conveniently stored without taking up space.

Ergonomic in day by day



Refilling coffee powder or water, emptying the filter or the drip tray. All compartments are directly accessible for maximum convenience.

Energy efficient

This feature keeps the power consumption to a minimum. In fact, less than 1 Watt per hour is needed in stand-by mode, automatic after 1 hour, saving resources and money

Classic milk frother



This Saeco espresso machine comes with the classic milk frother that baristas call a “Pannarello”. It dispenses steam and is immersed in milk to prepare gorgeous milk foam. Unleash your inner barista by preparing your delicious milk specialties the traditional way!



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Features

Brita Filter compatible: Optionable

Cupholder

Filterholder: Pressurized "Crema"

Hot water / Steam Nozzle

Interface: Rotary Switch

Suitable for pods

Pannarello: Plastic

Simultaneous brewing

Design

Colour: Black

Materials and finishing: ABS

Weight and dimensions

Product dimensions (L x D x H): 200 x 265 x 297 mm

Maximum cup height: 75 mm

Water tank capacity: 1.25 L

Product weight: 4 kg

Technical specifications

Cord length: 80 cm

Boiler material: Stainless steel (Inox)

Power: 950 W

Number of water boilers: 1 boiler

Country of origin: Designed in Italy, Made in China

