

PHILIPS

Steam generator
iron

PerfectCare Aqua

5 bar

290 g steam boost

Carry lock

2.5 L fixed watertank

GC8642



Ultra fast ironing

with no temperature adjustment required

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare Iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.

Carefree ironing, no temperature setting required

- Iron from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board
- Tested and approved by independent textile experts

Fast and powerful ironing

- Tap water friendly, refill anytime during ironing
- The safety auto off function automatically switches off
- Ready to use in 2 minutes with unlimited refill
- Our best gliding soleplate
- Saving energy with ECO mode
- Lock your iron securely to the base station



asimpleswitch.com

Highlights

Steam ready in 2 minutes



Steam is ready to use in 2min and can be refilled at anytime during ironing.

Refill tap water any time



Your steam generator iron is designed to use tap water. While ironing, when you run out of water in the watertank, you can refill it easily without waiting or turning your appliance off.

Safe rest



The Philips innovative OptimalTEMP technology guarantees no burn on all ironable fabrics. During ironing, no need to put your iron back to the base station, just leave the hot iron soleplate directly on the garments or cotton ironing board cover without additional resting accessory. It will not damage any of your ironable garments, neither the board. This makes your ironing easier with less wrist efforts.

Energy saving



By using the ECO mode, with reduced amount of steam, you can save energy without compromising on the ironing results.

Safety auto off



The safety auto off function automatically switches off the appliance if it has not been used for 10 minutes, to save energy.

T-ionicGlide soleplate



Our best gliding and most scratch resistant, 5star rated soleplate with integrated Titanium-Oxide layer

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer, reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

OptimalTEMP technology



Now you can iron from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust temperature 2) Powerful Cyclonic steam chamber which delivers powerful consistent steam, making ironing easier and faster.



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Calc management

Calc clean reminder

Calc clean solution: Easy De-calc

Suitable for tap water

Easy to use

Cord freedom (swivel): 180 degree cord freedom

Cord storage: Cord clip

Heat up time: 2 min

Hose length: 1.7 m

Hose storage: Hose storage compartment

Power cord length: 1.8 m

Refill any time

Safe for all fabrics: Even for delicates like silks

Safety auto off

Storage solution: Carry lock

Water tank capacity: 2500 ml

Filling and emptying water: Extra large filling hole

Fast & powerful crease removal

OptimalTEMP technology

Power: 2400 W

Safe rest

Soleplate: T-ionicGlide

Steam boost: 290 g

Steam tip

Variable steam settings

Vertical steaming

Pressure: Up to 5.4 bar pressure

Technical specifications

Voltage: 220- 240 V

