



Saeco Minuto
Super-automatic
espresso machine

- Pure
- Black



HD8760/01

Always your favorite coffee at just one touch

With the one-click removable brewing group

Only the Saeco Minuto super-automatic espresso machine delivers the real first bean to cup experience with maximum convenience, top-notch performance and large capacities in extra compact dimensions

Authentic Italian coffee perfection

- Coffee without waiting thanks to the quick heat boiler
- Every bean ground perfectly with our metal grinders

Advanced technology designed for coffee perfection

- Fine-tune the coffee's richness with 5 grinder settings

High comfort is part of the experience

- The fully removable brewing group can be cleaned in no time

 **Saeco**

PHILIPS

Saeco, a Philips brand



Highlights

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Metal grinders



Our metal grinders always guarantee impeccable grinding.

5-steps adjustable grinders



When it comes to the fineness of the grind, this machine never fails to satisfy. Different coffee blends require different levels of granularity for the full flavor to unfold. So the grind granularity of this machine has five adjustable settings - from the finest grind for a full-bodied espresso, to the coarsest for a lighter coffee.

Removable brewing group



Efficiency and ease of use were key inspirations when Saeco invented the first brewing group 30 years ago. And to this day, it still proves to be an inspired, resolute piece of technology. As always, it's so simple to clean – just remove it and wash it under the tap for a few seconds, then re-insert it just as easily.

Specifications

Country of origin

- Made in: Europe

Sustainability

- Power consumption brewing: 1850 W

General specifications

- One touch variety: 3
- Grinder settings: 5
- Customizing per drink: Adjustable coffee strength, Adjustable cup volume
- Coffee drinks: Espresso, Café Crème
- Suitable for: Whole coffee beans
- Cups at the same time: 2
- Ease of use and comfort: Removable spout, Removable drip-tray
- Type of boiler: Quick heat boiler
- Special functions: Ceramic grinder, Pre-brewing
- Ease of cleaning & maintenance: Automatic rinse cycle, Optional Brita water filter, Automatic descaling cycle, Removable brewing group

Finishing

- Material boiler: Stainless steel (Inox)
- Material drip tray: Stainless steel
- Material water tank: Plastic
- Material of main body: Plastic

Service

- 2-year guarantee

Technical specifications

- Brewing time one cup: 45 (espresso) to 100 (long coffee) sec
- Capacity water tank: 1.8 L
- Max. cup height: 152 mm
- Capacity bean container: 250 gr
- Cord length: 0.8 m
- Water boilers: 1
- Capacity waste container: 15 servings
- Frequency: 50 Hz
- Voltage: 230 V
- Pump pressure: 15 bar

Weight and dimensions

- Dimensions of product (WxDxH): 215 x 429 x 330 mm
- Weight of product: 7.5 kg

Design

- Color: Black

