



Gaggia
Manual Espresso

• Gaggia Baby

RI9301/49



GAGGIA'S ICONIC MODEL SINCE 1977

TRADITIONAL PROFESSIONAL BOILER AND FILTER HOLDER

Traditional design but always up-to-date. Baby is the first coffee machines for home using and now relaunched with exclusive metal details, different models but maintaining the traditional heart : professional chromed brass filter holder.

Features

- Ground coffee and easy serve pods.
- Panarello steamer attachment
- Professional chromed brass filter holder and ring

Designed for timeless beauty and convenience

- 2 "perfect crema" coffee filter for ground coffee and pods

Professional bar performances

- Gaggia's solenoid valve
- Professional heavy filter holder
- Rotating Pannarello

Authentic Italian Espresso

- 15 bar pump
- Cup holder

GAGGIA
MILANO

HIGHLIGHTS

Panarello steamer attachment



Panarello steamer attachment rotates for easy access to froth milk in seconds. Also delivers hot water for tea and other hot drinks.

Chromed brass filter holder



Professional chromed brass filter holder and ring, as used in Gaggia's commercial machines, ensure a consistent temperature throughout the coffee making and dispensing process.

Gaggia's solenoid valve



Gaggia's solenoid valve delivers a widespread shower through the coffee, eliminating hotspots which can burn the coffee. Its precise pressurisation ensures no drips and leaves drier coffee grounds after brewing, for easy cleaning.

Ground coffee



Gaggia's manual machines come with a coffee filter for 1 & 2 cups of ground coffee, and a special filter for ESE (easy serve espresso) pods.

Professional filter holder



It is the same filter holder used in the Gaggia commercial machines and ensure yo a real Barista experience and result in cup

2 "perfect crema" coffee filte



2 "perfect crema" coffee filter for ground coffee and pods

15 bar pump



High pressure ensures that the ground coffee entire aroma is always fully extracted

Cup holder



With this pratical feature you can store your espresso cups and glasses right on the espresso machine - always within reach and conveniently stored without taking up space.

Rotating Pannarello



Rotating Pannarello

SPECIFICATIONS

Weight and dimensions

- Product dimensions: 245x265x400 cm
- Product weight: 7,3 kg

Technical data

- Frequency: 60 Hz
- Power: 1425 W
- Pump Pressure: 15 bar
- Voltage: 120 V
- Boiler: Anodized

Features

- Brita Filter compatible
- Cupholder

- Hot water / Steam Nozzle
- Interface: Direct buttons
- Pannarello: Plastic
- Removable watertank
- Simultaneous brewing
- Suitable for Kit Pods E.S.E.

Water tank

- Water tank capacity: 1,6 l
- Detachable water tank

Design

- Colour: black
- Materials and finishing: asbs