

PHILIPS

Jamie Oliver Food
processor

1000 W

3.4 L bowl

8 accessories

HR7782/00



Speed up your cooking

Serrated knife for your food processor

"I use my food processor every day. This one chops like a ninja and speeds up every aspect of my cooking, whether I'm slicing, shredding or mixing. It can even be used to knock up a quick ice cream. It's a great kitchen shortcut" Jamie O.

Saves time while preparing fresh healthy food

- Adjustable slicing disc for thin to thick slices (1 - 7 mm)
- Reversible shredding disc (fine or coarse)
- Metal double balloon beater for egg whites and cream
- Innovative serrated knife for quick frozen desserts

Get inspired to create more fresh meals

- Exclusive Jamie Oliver recipes for inspiration
- Visit www.philips.com/jamieoliver for more tips

Confidently control power and speed settings

- PowerChop technology for superior chopping performance

Easy processing and effortless cleaning

- Dishwasher safe accessories



asimpleswitch.com

Highlights

Reversible shredding disc



Cooking delicious meals for friends and family doesn't have to be time consuming. This reversible shredding disc ensures that onions, carrots, zucchinis and potatoes are grated in seconds. Useful for curries, salads, stews and gratins - and maybe a great way to bring more vitamins and fibres into your diet!

Metal double balloon beater



The double metal balloon beater creates fluffy egg whites and perfectly whipped cream. For best results, use speed 1, which ensures the most fluffy results. Creating delicious desserts has never been easier!

Innovative serrated knife



Busy parents can now treat their children (or themselves) to healthy frozen desserts. This innovative serrated knife makes instant "ice creams" from frozen berries, yoghurt and honey in a matter of seconds. Thanks to the serrated edges, crushing ice cubes is quick and simple too.

Adjustable slicing disc



"We all lead increasingly busy lives, so saving time in the kitchen while still putting tasty and nutritious food on the table is incredibly important. I want busy parents to feel as comfortable as possible using the new Food Processor, which will give back some extra special time to spend with family or friends by reducing meal preparation time." This slicing disc is easily adjusted to enable a variety of different thicknesses of apples, potatoes or other ingredients.

Exclusive Jamie Oliver recipes



Each product in the range of Jamie's Tools by Philips Jamie Oliver comes with exclusive recipes from Jamie to help prepare a range of easy, fresh dishes that all the family will love.

Jamie's Tools



"For me, it's about encouraging more people to enjoy cooking and to feel as comfortable and confident as possible using this kit. And, ultimately, I set out to design a range that I would be genuinely happy to have and use in my own kitchen. Every piece of kit from the Jamie's Tools range by Philips Jamie Oliver

has a splash of lovely cornflower blue, the color I chose to match the clean retro shapes we've used. This stuff is meant to be shown off, not hidden away in cupboards."

Dishwasher safe accessories



All Philips Food Processor accessories included in your box are dishwasher safe.

PowerChop technology



PowerChop

PowerChop technology is a combination of blade shape, cutting angle and inner bowl that provides a superior chopping result in both soft and hard ingredients. It is also perfect for making purées and mixing your cake batters!



asimpleswitch.com

Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Specifications

Accessories

Adjustable slicing disc: 1-7 mm

Balloon beater: For whipping, whisking, mixing and emulsifying

Citrus press: For pressing of citrus fruits

Kneading tool: For (heavy) kneading, mixing dough, batter

Number of inserts/discs: 2

Stainless steel chopping knife: Beating, chopping, creaming, crumbling, cutting, folding in, mashing, mincing

Stainless steel S-blade

Design specifications

Bowl including lid and blender: SAN

Color(s): Star white & horizon blue

Disks, chopping blade: Stainless steel

Function buttons: Pulse

Housing: ABS

Kneading tool, citrus press: PP

Knife holder, balloon beater: POM

Pusher, inner pusher: ABS, SAN

Speed knob: ABS

General specifications

Integrated cord storage

Non-slip feet

Speeds: 2 + pulse

RPM-Blender&Grinder Mill(max): Up to 20000 rpm

RPM-Bowl(max): Up to 1700 rpm

RPM-Bowl(min): Up to 575 rpm

Main unit with bowl: 289x254x436 mm

Technical specifications

Cord length: 1.2 m

Frequency: 50/60 Hz

Safety: Lid & bowl detection, mechanical 1.5 sec brake

Voltage: 220-240 V

Dimensions and weight

Packaging dimensions (L×W×H):

34.5x53x27 cm

Product dimensions (L×W×H):

324.3x273.6x412.1 mm

Country of origin

China

