

PHILIPS

Saeco

Super-automatic
espresso machine

Syntia

Integrated milk jug & frother

Stainless steel



HD8838/47



SYNTIA

Live the pleasure of Italian espresso at home
compact and stylish bean-to-cup system

the perfect synthesis between compactness, performance, design and premium materials

Authentic Italian coffee perfection

- Integrated automatic milk function with Easy Refill
- Coffee without waiting thanks to the quick heat boiler
- Coffee without burnt taste thanks to 100% ceramic grinders

Set the beverages to suit your taste

- Save your favorite coffee settings
- Play with the coffee's richness with our adjustable grinders
- Avoid heat loss and fit every cup with our adjustable spout

Ease of cleaning and maintaining

- Always a clean machine thanks to auto-clean and descaling
- Easy cleaning thanks to removable brewing group
- Easy cleaning thanks to dishwasher-safe parts
- Cutting-edge design with stainless steel finish

Highlights

Stainless steel



The cutting-edge design of your Saeco espresso machine is rounded off by the stainless steel finish. The stainless steel provides a high quality look and will be a highlight on your kitchen counter tops. It also gives greater resistance for a long-lasting performance.

100% ceramic grinders



This espresso machine is equipped 100% ceramic grinders. Saeco uses ceramic grinders because of their consistent grind without overheating the coffee bean for an impeccable espresso. Ceramic also ensures long-lasting performance and a totally silent operation.

Quick heat boiler



The Saeco quick heat boiler technology ensures your machine is always ready. Now you won't have to wait between brewing each espresso, but can prepare coffee after coffee.

Saves your coffee settings



You will always get a perfect cup of espresso brewed just for you, according to your personal preference, thanks to our innovative memo function to adjust the coffee length, strength and temperature. Enjoy a superb coffee drink in your favorite cup with just the press of a button.

Adjustable spout



The adjustable spout on our espresso machines will fit every cup and thus prevents the coffee splashing or cooling down while pouring in your cup. This way your espresso is always served at the right temperature while maintaining a clean machine.

Dishwasher-safe parts



For your convenience, you can put the Saeco's drip tray and milk frother or milk carafe in the dishwasher. This will save time and ensure a hygienic cleaning.

5 step adjustable grinders



Different coffee blends require different levels of granularity for the full flavor to unfold. The grind granularity of this espresso machine can be adjusted in 5 settings, from the finest grind, for a full bodied espresso, to the coarsest, for a lighter coffee.

Removable brewing group



The brewing group, a Saeco invention, is the heart of our espresso machines, ensuring automation. The brewing group is, depending on the model, easily accessible from the front or side. It can be removed effortlessly for easily cleaning by rinsing under the tap ensuring maximum hygiene.

Specifications

Service

1-year guarantee

Perfect Espresso

Espresso technology: Saeco adapting system,
Aroma-system: pre-brewing

Technical specifications

Supported coffee types: Ground coffee, Whole coffee beans

Water pressure in pump: 15 bar (perfect espresso)

Removable brewing group

Country of origin: Designed in Italy, Made in Italy

Cord length: 80 cm

Number of water boilers: 1 boiler

Frequency: 60 Hz

Power: 1400 W

Voltage: 120 V

Boiler material: Stainless steel (Inox)

Multi-Beverage

Milk Variations: Integrated auto milk function

Easy to use

Cleaning and maintenance: Automatic coffee circuit rinse

Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Frontal access to all function, Rapid steam, Removable brewing group, Removable watertank

Weight and dimensions

Product weight: 8.9 kg

Product dimensions (L x D x H): 330 x 450 x 415 mm

Coffee bean capacity: 250 gr

Waste container capacity: 8 servings

Water tank capacity: 1.2 L

Maximum cup height: 110 mm

Design

Colour: Stainless steel

Materials and finishing: Stainless steel

