



Gaggia
Full automatic
espresso machine

• Gaggia Brera

RI9305/48

PRESS A BUTTON AND ENJOY YOUR FAVOURITE ESPRESSO

COMPACT, TRADITIONAL DESIGN AND SIMPLE TO USE

Who said the you'll never get at home the same great espresso they make at caffetteria? Brera Gaggia gives you tha professional thing right in the comfort of your kitchen. Select the strength and legth according to your personal taste.

Features

- Brew a different blend without changing the beans.
- Automatically switches to standby after one hour

Easy of cleaning and maintaining

- Automatic coffee circuit cleaning
- Descaler Warning

Easy to use

- Frontal access for easy filling and emptying
- One click removable brewing group

Family friendly

- Energy efficient

Perfect espresso

- Ceramic grinders for Aroma preserving
- Pre-brewing function for flavor enhancing

GAGGIA
MILANO

HIGHLIGHTS

SPECIFICATIONS

Ground coffee compartment



Variety is still an option; via the ground coffee compartment you can brew a different blend without changing the beans.

Standby mode



Automatically switches to standby after one hour, then uses less than one kw per hour when in standby mode.

Auto coffee circuit cleaning



This feature makes sure that each and every coffee is as fresh as possible: Before going into and when returning from stand-by mode, the machine automatically cleans its coffee circuit.

Ceramic grinders

These high-tech grinders beat the competition's steel grinders on many levels: always perfectly Italian

taste because of consistently accurate grinding without overheating, supreme longevity, super-silent operation.

Descaler Warning



Dedicated led to advise the end user that the machine needs to be descaled

Energy efficient

This feature keeps the power consumption to a minimum. In fact, less than 1 Watt per hour is needed in stand-by mode, automatic after 1hour, saving resources and money

Easy frontal access

All machine elements you need to reach during your day-by-day enjoyment (water, coffeebeans and coffee grounds container, drip tray, removable brewing group) are completely independent and reachable either from the front or from the top.

Pre-brewing system

Pre-brewing for even more enjoyment. Thanks to the Pre-brewing Technology, the coffee grounds are moistened before the actual brewing process – ensuring that the aroma can unfold even better.

One click removable group



The brewing group – a Saeco invention- is the heart of our machines, ensuring that the machine makes everything on its own. Thanks to its easy access, you can effortlessly remove it for regular cleaning with just one click.

Weight and dimensions

- Product dimensions: 45.5 x 33.0 x 42.5 cm
- Coffee bean capacity: 250 gr
- Dump box capacity: 8 servings
- Product weight: 8,5 kg

Multi-Beverage

- Milk Variations: Pannarello: milk frothing

Technical data

- Boiler: Stainless steel
- Frequency: 60 Hz
- Power: 1250 W
- Pump Pressure: 15 bar
- Voltage: 120 V

Easy to use

- Usage: Adjustable coffee dispenser, Bypass for grinded coffee, Rapid steam, Removable brewing group, Removable watertank

Perfect Espresso

- Espresso technology: Saeco adapting system

Water tank

- Detachable water tank
- Water tank capacity: 1,2 l

Design

- Colour: Silver
- Materials and finishing: abs/stainless steel

Energy saving

- Energy saving: Automatic stand-by

Features

- Brita Filter compatible
- Cupholder
- Hot water / Steam Nozzle
- Pannarello: Stainless Steel