



Gaggia
Super-automatic
espresso machine

• Gaggia Unica

RI9933/70

GAGGIA UNICA WILL SURPRISE YOU!

JUST PRESS A BUTTON TO HAVE A PERFECT ESPRESSO

easy and clean maintenance

Features

- Adjustable dispensing head to fit every cup
- Durable ceramic grinder for pure coffee aroma
- Classic milk frother for a tasty Cappuccino
- Program the buttons with your favourite coffee drinks
- Easy cleaning thanks to removable brewing group
- Energy-saving Stand-by mode

GAGGIA
MILANO

HIGHLIGHTS

SPECIFICATIONS

Adjustable dispensing head



The dispensing head on your Gaggia machine is adjustable in height to accommodate different cup sizes.

Personalize machine buttons



Programme the dispensing buttons on your electronic control panel to suit your own personal coffee taste.

Durable ceramic grinder



Because a metal grinder might burn the coffee beans while grinding, all Gaggia's Espresso machines are equipped with an extremely durable ceramic grinder. A ceramic grinder will retain the purity of the coffee aroma while being equally durable to a metal grinder. Additionally the coffee grind can be adjusted from coarse to fine, just as you prefer.

Removable brewing group



The removable brewing group in your full-automatic Espresso machine allows for easy cleaning and maintenance and can even be replaced separately if necessary. This saves money and increases the machine hygiene for a flawless coffee taste.

Classic milk frother



The classic milk frother on this Gaggia Espresso machine, traditionally called "Panarello", turns milk into gorgeous milk froth within seconds for a Cappuccino, a Latte Macchiato or more. It also delivers hot water for tea.

Stand-by mode



Your coffee machine switches off automatically after one hour. In the energy efficient stand-by mode your Gaggia machine will drain less than 1kW/h and save you money compared to other espresso machines.

Weight and dimensions

- Water tank capacity: 1,7 L
- Product weight: 9 kg
- Coffee bean capacity: 250 gr
- Waste container capacity: 14 servings
- Product dimensions: 32x37,2x46,1 cm

Technical data

- Boiler: Stainless steel
- Frequency: 50 Hz
- Power: 1300 W
- Voltage: 230 V
- Pump Pressure: 15 bar

Features

- Brita Filter compatible
- Cupholder
- Hot water / Steam Nozzle
- Pannarello: Plastic
- Removable watertank

Energy saving

- Energy saving: Automatic stand-by

Design

- Colour: black/silver
- Materials and finishing: abs

Easy to use

- Usage: Adjustable coffee dispenser, Removable brewing group, Removable watertank

Multi-Beverage

- Milk Variations: Pannarello: milk frothing