

PHILIPS

Steam generator
iron

PerfectCare Pure

Max 5 bar pump pressure

245 g steam boost

PureSteam cartridge

GC7636/30



Faster and easier ironing

with OptimalTEMP technology

Iron your garments without adjusting temperature thanks to the revolutionary OptimalTEMP technology. Most compact steam generator, easy to store & carry. 99% calc free, Pure Steam anti-scale cartridges increase life by 5 times

Fast and powerful ironing

- Max 5 bar pump pressure
- 1.5 L water tank, up to 2 hours of ironing
- 99% calc-free with PureSteam Anti-scale cartridge
- The most compact and lightest steam generator
- Tap water friendly, refill anytime during ironing
- Automatically turned off for safety and energy saving
- Lock your iron securely to the base station
- Steam boost up to 245 g
- Our best gliding soleplate

Carefree ironing, no temperature setting required

- Iron from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board

Highlights

Max 5 bar pump pressure



The more steam, the faster the ironing. Consistent powerful steam is generated which penetrates deep inside the garments making ironing faster and better. Steam power can be regulated to fit your needs.

OptimalTEMP technology



"Now you can iron from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust temperature 2) Compact ProVelocity steam engine delivers more steam for ironing faster. It enables compact design of your steam generator for easier storage"

Safe rest



The Philips innovative OptimalTEMP technology guarantees no burn on all ironable fabrics. During ironing, no need to put your iron back to the base station, just leave the hot iron

soleplate directly on the garments or cotton ironing board cover without additional resting accessory. It will not damage any of your ironable garments, neither the board. This makes your ironing easier with less wrist efforts.

1.5 L water tank



Thanks to the 1.5 L watertank capacity, you can iron up to 2 hours continuously without any refills. The large filling hole makes the refilling fast. You can either fill your steam generator iron under the tap or use a jug / large bottle.

99% calc-free

PureSteam Anti-scale cartridge filters 99% of scale from tap water. It ensures consistent steam flow and prevents calc residues on clothes.

Compact and light

The compact design makes your appliance easy to storage. Space will never be an issue again! As it is very light, your appliance is easy to carry. Its light weight iron will make your ironing much more comfortable.

Refill tap water any time



Your steam generator iron is designed to use tap water. While ironing, when you run out of water in the watertank, you can refill it easily without waiting or turning your appliance off.

Automatic shut-off



The safety auto off function automatically switches off the appliance if it has not been used for a few minutes, also saving energy.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer, reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.

Steam boost up to 245 g

The steam boost can be used for vertical steaming and tough creases.

T-ionicGlide soleplate



Our best gliding and most scratch resistant, 5star rated soleplate with integrated Titanium-Oxide layer

Specifications

Calc management

Suitable for tap water

Calc clean solution: PureSteam Anti-scale cartridge

Calc clean reminder

Easy to use

Water tank capacity: 1500 ml

Filling and emptying water: Extra large filling hole

Refill any time

Heat up time: 2 min

Safety auto off

Storage solution: Carry lock

Hose storage: Hose storage compartment

Cord storage: Cord clip

Hose length: 1.6 m

Safe for all fabrics: Even for delicates like silks

Power cord length: 1.8 m

Fast & powerful crease removal

Soleplate: T-ionicGlide

OptimalTEMP technology

Vertical steaming

Steam tip

Power: 2400 W

Steam boost: 245 g

Continuous steam output: 120 g/min

Pressure: Max 5 bar

Safe rest

Turbo steam

Variable steam settings

Sustainability

User manual: 100% recycled paper

Weight and dimensions

Packaging dimensions (WxHxL): 40 x 23 x 28 cm

Product dimensions (WxHxL): 35.4 x 19.3 x 22.4 cm

Weight of iron: 1.2 kg

Weight of iron + base: (with 1 cartridge) 3.19 kg

