



Philips PerfectCare Aqua
Silence
Steam generator iron

Up to 6.2 bar pressure

330 g steam boost
Carry lock
2.5 L fixed watertank



GC8650/80

Ultra fast and quiet ironing

with no temperature adjustment required

Iron any ironable garment from silk, to linen, to cotton, to cashmere...in any order, without having to adjust. Your Philips PerfectCare Iron delivers fast results without risk of burn or shine for all your garments. Truly simple ironing.

Carefree ironing, no temperature setting required

- Silent steam technology: Powerful steam with minimum sound
- Iron from jeans to silk with no temperature setting required
- Safe to leave the hot soleplate on the ironing board
- Tested and approved by independent textile experts

Fast and powerful ironing

- Descale effectively and easily your appliance to prolong it
- Tap water friendly, refill anytime during ironing
- The safety auto off function automatically switches off
- Ready to use in 2 minutes with unlimited refill
- Up to 6.2 bar pressure
- Large 2.5 L fully visible water tank
- Our best gliding soleplate
- Saving energy with ECO mode
- Lock your iron securely to the base station



asimpleswitch.com

PHILIPS

Highlights

Silent steam Technology



Enjoy ironing with family around or while watching TV, without being disturbed by the noise of the steam. Silent steam technology delivers quiet yet very powerful steam. The steam generator is fitted with silencing steam filters to reduce the noise of the steam, and a sound-absorbing platform to reduce the noise of the pump in the base.

OptimalTEMP technology



Now you can iron from jeans to silk with no temperature setting required. Guaranteed no burn on all ironable fabrics. Revolutionary technology with the 1) Advanced Smart Control Processor which controls precisely the soleplate temperature. You do not need to adjust temperature 2) Powerful Cyclonic steam chamber which delivers powerful consistent steam, making ironing easier and faster.

Easy De-Calc



Ultra long lasting steam performance: Philips' exclusive Easy De-Calc function provides the ideal way to get rid of limescale and extend the lifetime of your steam generator iron. Your iron will remind you with light and sound when to perform cleaning. Only when your appliance is cold, simply open the Easy De-Calc knob, and collect the dirty water and scale in a cup.

Energy saving



By using the ECO mode, with reduced amount of steam, you can save energy without compromising on the ironing results.

Refill tap water any time



Your steam generator iron is designed to use tap water. While ironing, when you run out of water in the watertank, you can refill it easily without waiting or turning your appliance off.

Safety carry lock



Your steam generator iron comes with a safety carry lock. You can lock your iron safely on the base, making it safer, reducing the risk of people touching the hot soleplate. You can also carry the steam generator easily.



Philips Green Logo

Philips Green Products can reduce costs, energy consumption and CO2 emissions. How? They offer a significant environmental improvement in one or more of the Philips Green Focal Areas – Energy efficiency, Packaging, Hazardous substances, Weight, Recycling and disposal and Lifetime reliability.

Steam generator iron
Up to 6.2 bar pressure 330 g steam boost, Carry lock, 2.5 L fixed watertank

Specifications

Calc management

- Calc clean reminder
- Calc clean solution: Easy De-calc
- Suitable for tap water

Easy to use

- Cord freedom (swivel): 180 degree cord freedom
- Cord storage: Cord clip
- Heat up time: 2 min
- Hose length: 1.7 m
- Hose storage: Hose storage compartment
- Low water alarm
- Power cord length: 1.8 m
- Refill any time
- Safe for all fabrics: Even for delicates like silks
- Safety auto off
- Storage solution: Carry lock
- Water tank capacity: 2500 ml
- Filling and emptying water: Extra large filling hole

Fast & powerful crease removal

- OptimalTEMP technology
- Power: 2400 W
- Safe rest
- Silent Steam Technology
- Soleplate: T-ionicGlide
- Steam boost: 330 g
- Steam tip
- Vertical steaming
- Pressure: Up to 6.2 bar pressure

Technical specifications

- Voltage: 220 - 240 V
- Product dimensions: 36.2 x 27 x 26.3 cm
- Weight of iron: 1.1 kg
- Weight of iron + base: 4.5 kg



Issue date 2018-03-28

Version: 11.0.1

© 2018 Koninklijke Philips N.V.
All Rights reserved.

Specifications are subject to change without notice.
Trademarks are the property of Koninklijke Philips N.V.
or their respective owners.

www.philips.com

* In the category of pressurised unlimited steam generator